


# MODEL TS3832

# SPOTNAILS<sup>®</sup>

DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd  
Rolling Meadows, IL 60008  
Phone : 847-259-1620



5/17/2005

## SPOTNAILS MODEL TS3832

Ref No.	Part No.	Description
01	P-24370	Screw
02	P-96118	Bushing
03	P-70046	Exhaust Deflector
04	P-64377	O-Ring
05	P-32217	Washer
06	P-24358	Cap Screw
07	P-32211	Flat Washer
08	P-60180	Cap
◆	09	P-15193 Exhaust Seal
◆	10	P-64384 O-Ring
◆	11	P-18331 Poppet Spring
◆	12	P-64232 Poppet O-Ring
◆	13	P-63042 Poppet
◆	14	P-64422 Piston Stop O-Ring
◆	15	P-64234 Cylinder Seal O-Ring
◆	16	P-03081 Guide Spacer
◆	17	P-62079 Gasket
◆	18	P-05106 Cylinder
◆	19	P-64235 Cylinder O-Ring
◆	20	P-64423 O-Ring
◆	21	P-64424 Piston O-Ring
◆	22	P-06236 Driver Blade
◆	23	AS-06054 Piston & Driver Assembly
◆	24	P-15121 Bumper
◆	25	P-15124 Return Seal
◆	26	P-01271 Body
◆	27	P-64425 O-Ring
◆	28	P-60175 End Cap
◆	29	P-08481 Wear Plate
◆	30	P-26125 Nut
◆	31	P-24300 Screw
◆	32	AS-10051 Front Plate Assembly
◆	33	P-07262 Pin

Ref No.	Part No.	Description
34	P-24452	Screw
35	P-07290	Pin
36	P-53165	Safety Guide
37	P-18328	Spring
38	AS-53057	Safety Assembly
39	P-64239	O-Ring
40	P-22114	Bleeder Valve
41	P-64241	O-Ring
42	P-18227	Spring
43	P-22179	Plunger
44	P-64240	O-Ring
45	AS-21014	Trigger Assembly
46	P-07327	Trigger Pin
47	P-26142	Nut
48	P-32170	Washer
49	P-13046	Bracket
50	P-24307	Screw
51	AS-99086	Magazine Cover Assembly
52	P-18332	Spring
53	P-05098	Fixed Spacer
54	P-24310	Screw
55	P-12352	Track
56	P-18233	Spring Clip
57	P-18232	Negator Spring
58	P-09158	Pusher
59	AS-53061	No Mar Tip Assembly
60	P-96129	No Mar Tip
61	P-32227	Washer
62	P-26165	Nut
63	P-07356	Step Pin
64	P-07353	Pin
65	AS-04036	Latch Assembly
66	P-64434	O-Ring

◆ Parts Included In AS-97309 O-Ring And Seal Kit