


MODEL TS4825

SPOTNAILS®



SPOTNAILS MODEL TS4825

Ref No.	Part No.	Description
01	P-24370	Screw
02	P-96118	Bushing
03	P-70046	Exhaust Deflector
04	P-64377	O-Ring
05	P-32217	Washer
06	P-24358	Cap Screw
07	P-32211	Flat Washer
08	P-60180	Cap
09	P-15193	Exhaust Seal
10	P-64384	O-Ring
11	P-18331	Poppet Spring
12	P-64232	Poppet O-Ring
13	P-63042	Poppet
14	P-64422	Piston Stop O-Ring
15	P-64234	Cylinder Seal O-Ring
16	P-03081	Guide Spacer
17	P-62079	Gasket
18	P-05106	Cylinder
19	P-64235	Cylinder O-Ring
20	P-64423	O-Ring
21	P-64424	Piston O-Ring
22	P-06244	Driver Blade
23	AS-06064	Piston & Driver Assembly
24	P-15121	Bumper
25	P-15124	Return Seal
26	P-01271	Body
27	P-64425	O-Ring
28	P-60175	End Cap
29	P-15196	Return Seal
30	P-08485	Wear Plate
31	P-24300	Screw
32	P-26125	Nut
33	P-24452	Screw
34	P-07239	Pin

Ref No.	Part No.	Description
35	AS-10051	Front Plate Assembly
36	P-07262	Pin
37	P-53165	Safety Guide
38	P-18328	Spring
39	AS-53057	Safety Assembly
40	P-64239	O-Ring
41	P-22114	Bleeder Valve
42	P-64241	O-Ring
43	P-18227	Spring
44	P-22179	Plunger
45	P-64240	O-Ring
46	AS-21014	Trigger Assembly
47	P-07327	Trigger Pin
48	P-24307	Screw
49	P-32170	Washer
50	P-26142	Nut
51	P-13041	Bracket
52	P-12450	Magazine Cover
53	P-18131	Spring Clip
54	P-18132	Negator Spring
55	P-12451	Magazine
56	P-03053	Spacer
57	P-09201	Pusher
58	P-24319	Screw
59	P-24310	Screw
60	P-64434	O-Ring
61	AS-04035	Latch Assembly
62	P-07356	Step Pin
63	P-07353	Spiral Pin
64	AS-53061	No Mar Tip Assembly
65	P-96129	No Mar Tip
66	P-32227	Washer
67	P-26165	Nut

◆ Parts Included In AS-97310 O-Ring And Seal Kit