


# MODEL TS5825F

**SPOTNAILS®**  
DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd  
Rolling Meadows, IL 60008  
Phone : 847-259-1620



## SPOTNAILS MODEL TS5825F

Ref No.	Part No.	Description	Ref No.	Part No.	Description		
	01	P-24370	Screw	34	P-07262	Pin	
	02	P-96118	Bushing	◆	35	P-64239	O-Ring
	03	P-70046	Exhaust Deflector		36	P-22114	Bleeder Valve
	04	P-64377	O-Ring	◆	37	P-64241	O-Ring
	05	P-32217	Washer		38	P-18227	Spring
	06	P-24358	Cap Screw		39	P-22179	Plunger
	07	P-32211	Flat Washer	◆	40	P-64240	O-Ring
	08	P-60180	Cap		41	P-07327	Trigger Pin
◆	09	P-15193	Exhaust Seal		42	AS-21014	Trigger Assembly
◆	10	P-64384	O-Ring		43	P-13078	Bracket
	11	P-18331	Poppet Spring		44	P-32170	Washer
◆	12	P-64232	Poppet O-Ring		45	P-24307	Screw
	13	P-63042	Poppet		46	P-24300	Screw
◆	14	P-64422	Piston Stop O-Ring		47	P-10342	Stationary Plate
◆	15	P-64467	Cylinder Seal O-Ring		48	P-32228	E Ring
	16	P-03081	Guide Spacer		49	P-24620	Screw
◆	17	P-62079	Gasket		50	P-18233	Spring Clip
	18	P-05106	Cylinder		51	P-18232	Negator Spring
◆	19	P-64235	Cylinder O-Ring		52	P-20035	Negator Spring Drum
◆	20	P-64423	O-Ring		53	AS-12211	Magazine Cover Assembly
◆	21	P-64424	Piston O-Ring		54	P-18454	Spring
	22	P-06235	Driver Blade		55	P-05107	Fixed Spacer
	23	AS-06107	Piston & Driver Assembly		56	P-24353	Screw
	24	P-15121	Bumper		57	P-24311	Screw
◆	25	P-15161	Return Seal		58	P-13127	Bracket
	26	P-01271	Body		59	P-18570	Flat Spring
	27	P-64425	O-Ring		60	P-10343	Removable Front Plate
	28	P-60175	End Cap		61	P-10344	Swivel Front Plate
◆	29	P-64240	O-Ring		62	P-08514	Wear Plate
◆	30	P-15214	Return Seal		63	P-07497	Pin
	31	P-53165	Safety Guide		64	P-09244	Pusher
	32	P-18328	Spring		65	P-12578	Magazine
	33	AS-53092	Safety Assembly		66	P-24370	Screw

◆ Parts Included In AS-97393 O-Ring And Seal Kit