


MODEL X1S1640RFH

SPOTNAILS®
 DIVISION OF PEACE INDUSTRIES, LTD.
 1100 Hicks Rd
 Rolling Meadows, IL 60008
 Phone : 847-259-1620



SPOTNAILS MODEL X1S1640RFH

Ref No.	Part No.	Description	Ref No.	Part No.	Description	
01	P-99286	Handle Grip	44	P-07327	Trigger Pin	
02	P-99287	Handle	45	P-07262	Pin	
03	P-99288	Upper Trigger Link	♦	46	P-64332	Valve Housing O-Ring
04	P-99289	90° Elbow		47	P-22144	Trigger Valve Cap
05	P-32239	Washer	♦	48	P-64333	O-Ring
06	P-32240	Washer	♦	49	P-64334	O-Ring
07	P-24495	Screw	♦	50	P-64335	O-Ring
08	P-96137	Upper Bushing		51	P-22145	Pilot Valve
09	P-99321	Trigger Connecting Rod	♦	52	P-64336	O-Ring
10	P-96138	Lower Bushing		53	P-18227	Spring
11	P-24496	Cap Screw-4	♦	54	P-64383	Plunger O-Rings-2
12	P-32211	Flat Washer-4		55	AS-22037	Plunger Assembly
13	P-99322	Mounting Plate Assembly	♦	56	P-64328	O-Ring
14	P-96139	Cap Spacers		57	AS-21031	Trigger Assembly (Blue)
15	P-99292	Lower Trigger Link		58	P-26126	Nut
16	AS-99105	Universal Walking Stick		59	P-32170	Washer-5
17	P-70058	Exhaust Deflector		60	P-13128	Bracket
18	P-60221	Cap		61	P-24301	Screw-2
♦	19	P-15187	Exhaust Seal	62	P-26159	Nut Plate
♦	20	P-64378	O-Ring	63	P-24450	Screw
21	P-18327	Poppet Spring		64	P-24430	Screw
♦	22	P-64601	Poppet O-Ring	65	P-24317	Screw
23	P-63055	Poppet		66	P-32229	Washer
♦	24	P-64379	Piston Stop o-Ring	67	P-12417	Magazine Cover
♦	25	P-64602	Cylinder Seal O-Ring	68	P-07335	Negator Spring Pin
♦	26	P-62094	Gasket	69	P-18334	Negator Spring
♦	27	P-64617	Piston O-Ring	70	P-24434	Screw
28	AS-06120	Piston & Driver Assembly		71	P-10285	Stationary Front Plate
29	P-03125	Guide Spacer		72	P-24358	Screw-2
30	P-05131	Cylinder		73	P-99293	Front Block
♦	31	P-64603	Cylinder O-Ring	74	P-24497	Screw
♦	32	P-64604	O-Ring	75	P-10347	Removable Front Plate
33	P-03126	Cylinder Guide		76	AS-99088	Wear Plate Filler
♦	34	P-64605	O-Ring	77	P-08517	Wear Plate
35	P-15273	Bumper		78	P-07357	Pin
36	P-15198	Return Seal		79	P-18333	Latch Spring
♦	37	P-64240	O-Ring-2	80	P-04062	Quick Clear Latch
38	P-01308	Body		81	P-07334	Pin
39	P-64312	O-Ring		82	P-99294	Rear Block
40	P-60156	End Cap		83	P-12410	Magazine
41	P-53165	Safety Guide		84	P-09211	Pusher
42	P-18328	Spring		85	P-97454	Filter (Optional)
43	AS-53087	Safety Assembly		86	P-18267	Spring

♦ Parts Included In AS- 97403 O-Ring And Seal Kit