


# MODEL X1S6650

**SPOTNAILS<sup>®</sup>**  
 DIVISION OF PEACE INDUSTRIES, LTD.  
 1100 Hicks Rd  
 Rolling Meadows, IL 60008  
 Phone : 847-259-1620



## SPOTNAILS MODEL X1S6650

Ref No.	Part No.	Description	Ref No.	Part No.	Description
01	P-24300	Cap Screw-4	35	P-64333	O-Ring
02	P-32211	Flat Washer-4	36	P-64334	O-Ring
03	P-70058	Exhaust Deflector	37	P-64335	O-Ring
04	P-60221	Cap	38	P-22145	Pilot Valve
◆ 05	P-15187	Exhaust Seal	39	P-64336	O-Ring
◆ 06	P-64378	O-Ring	40	P-18227	Spring
07	P-18327	Poppet Spring	41	P-64383	Plunger O-Rings-2
◆ 08	P-64601	Poppet O-Ring	42	AS-22037	Plunger Assembly
09	P-63055	Poppet	43	P-64328	O-Ring
◆ 10	P-64379	Piston Stop o-Ring	44	P-18267	Spring
◆ 11	P-64602	Cylinder Seal O-Ring	45	AS-21031	Trigger Assembly (Blue)
◆ 12	P-62094	Gasket	46	P-24370	Screw
◆ 13	P-64617	Piston O-Ring	47	P-24353	Screw-3
14	P-06301	Driver Blade	48	P-13129	Bracket
15	AS-06109	Piston & Driver Assembly	49	P-32170	Washer-3
16	P-03125	Guide Spacer	50	P-24301	Screw-2
17	P-05131	Cylinder	51	P-32229	Washer
◆ 18	P-64603	Cylinder O-Ring	52	P-12385	Magazine Cover
◆ 19	P-64604	O-Ring	53	P-24358	Screw-2
20	P-03126	Cylinder Guide	54	P-10276	Stationary Front Plate
◆ 21	P-64605	O-Ring	55	P-07253	Spring Pin
22	P-15278	Bumper	56	P-10277	Removable Front Plate
23	P-15274	Return Seal	57	P-18251	Latch Spring
◆ 24	P-64240	O-Ring	58	P-08463	Wear Plate
25	P-01307	Body	59	P-07257	Magazine to Wear Plate Pin
26	P-64312	O-Ring	60	P-18131	Spring Clip
27	P-60156	End Cap	61	P-18298	Negator Spring
28	P-53165	Safety Guide	62	P-27179	Magazine
29	P-18328	Spring	63	P-04060	Quick Clear Latch
30	AS-53083	Safety Assembly	64	P-26142	Nut
31	P-07327	Trigger Pin	65	P-09159	Pusher
32	P-07262	Pin	66	AS-53088	Vinyl Siding Attachment Kit (Optional)
◆ 33	P-64332	Valve Housing O-Ring	67	P-97454	Filter (Optional)
34	P-22144	Trigger Valve Cap			

◆ Parts Included In AS-97403 O-Ring And Seal Kit