

# MODEL XBA1564

THIS TOOL EQUIPPED WITH  
A RESTRICTIVE TRIGGER


# SPOTNAILS<sup>®</sup>

DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd

Rolling Meadows, IL 60008

Phone : 847-259-1620



## SPOTNAILS MODEL XBA1564

Ref No.	Part No.	Description	Ref No.	Part No.	Description	
1	P-24370	Screw	36	P-18339	Spring	
2	P-96118	Bushing	37	AS-10048	Front Plate Assembly	
3	P-70041	Exhaust Deflector	38	P-24358	Screw	
4	P-64377	O-Ring	39	P-07327	Trigger Pin	
5	P-24456	Cap Screw	40	P-64240	O-Ring	
6	P-32211	Flat Washer	41	AS-21008	Trigger Assembly	
7	P-60172	Cap	42	P-64328	O-Ring	
8	P-15187	Exhaust Seal	44	AS-22037	Plunger Assembly	
◆	9	P-64378	O-Ring	45	P-64383	Plunger O-Rings
◆	10	P-18327	Poppet Spring	46	P-18227	Spring
◆	11	P-64028	Poppet O-Ring	47	P-64336	O-Ring
◆	12	P-63037	Poppet	48	P-22145	Pilot Valve
◆	13	P-64379	Piston Stop O-Ring	49	P-64335	O-Ring
◆	14	P-64380	Cylinder Seal O-Ring	50	P-64334	O-Ring
◆	15	P-03079	Guide Spacer	51	P-64333	O-Ring
◆	16	P-62070	Gasket	52	P-22144	Trigger Valve Cap
◆	17	P-03073	Body Spacer	53	P-64332	Valve Housing O-Ring
◆	18	P-64228	Piston O-Ring	54	P-24300	Screw
◆	19	AS-06046	Piston & Driver Assembly	55	P-24433	Screw
◆	20	P-64330	Cylinder O-Ring	56	P-32170	Washer
◆	21	P-05105	Cylinder	57	P-13074	Bracket
◆	22	P-64419	O-Ring	58	P-26142	Nut
◆	23	P-15188	Bumper	59	P-24353	Screw
◆	24	P-01267	Body	60	P-12418	Magazine Cover
◆	25	P-64312	O-Ring	61	P-12419	Magazine
◆	26	P-60156	End Cap	62	P-27182	Wear Insert
◆	27	P-15201	Return Seal	63	AS-09049	Pusher Assembly
◆	28	P-07262	Pin	64	P-18478	Negator Spring
◆	29	P-53165	Safety Guide	65	P-18338	Spring Retainer
◆	30	P-18328	Spring	66	P-97454	Filter (Optional)
◆	31	AS-53048	Safety Assembly	67	P-06232	Driver Blade
◆	32	P-03074	Spacer	68	AS-21019	Restrictive Trigger
◆	33	P-53170	Lower Safety	69	P-18267	Spring
◆	34	P-26125	Nut	70	AS-04040	Latch Assembly
◆	35	P-08473	Wear Plate	71	P-07297	Pin

◆ Parts Included in AS-97286 O-Ring and Seal Kit