

Leviosa Motor Troubleshooting Guide – Battery Power

Symptom – Leviosa Motor does not respond to commands from remote or App. A 'beep' sound from a shade during operation indicates low battery power. Replace batteries.



Leviosa Motor Troubleshooting Guide – Adapter or Hardwire Power

Symptom – Leviosa Motor does not respond to commands from remote or App. A 'beep' sound from a shade indicates low voltage.



^{*}See instructions BOTTOM of this page: https://leviosashades.com/pages/power-options