



**B+** = Lipo 3S/4S

**#** = PWM / SIGNAL

**G** = GND

**4T** = UART 4 TX (s.port telemetry)

**5R** = UART 5 RX (SBUS)

**ESC** = ESC POWER

**2R** = UART 2 RX

**2T** = UART 2 TX

**S** = Switched GND for BUZZER

**B+** = BATT + (LIPO)

**S** = SLED (serial LED)

**V** = + 5V