



Crypton Fabric Care Guide

Crypton Fabric Care Guide

To clean and maintain:

- 01 Vacuum Fabric regularly to avoid dust build up
- 02 Rotate cushions where possible to distribute wear
- 03 Attend to spills immediately

We recommend using a specialist reputable and professional fabric or leather cleaning company at least once every two years to keep your furniture looking good and to increase the life of your furniture by up to 30%

For more information about cleaning your upholstery, contact Acorn Furniture: hello@acornfurniture.co.nz or 0800 601 701

Stain and mark removal:

Crypton Care Stain Removers make cleaning upholstery simple and easy. Simply follow the steps below.

- 01 Remove any residue lightly rubbing the surface
- 02 Choose the appropriate Crypton Care stain remover (see guide below)
- 03 Spray, lightly brush, then gently blot up the stain

Crypton Stain Removers:

- 01 Crypton Care Purple - is designed to remove ink, grease and oil stains. Butter, Cosmetics, Crayon, Gum, Ink, Iodine, Lipstick, Mayonnaise, Mustard, Nail Polish, Oil, Red Drinks, Rust, Shoe Polish, Sun Block and Vegetable Oil
- 02 Crypton Care Gold - removes food, beverage and protein stains. Beer, Blood, Butter, Chocolate, Coffee, Cola, Grass, Jelly, Juices, Ketchup, Mildew, Milk, Mustard, Pain (Latex), Tea, Urine, Vegetable Oil, Vomit and Wine
- 03 Crypton Care Green - freshens and deodorizes fabric. A fabric freshener that deodorizes your fabric and helps prevent mildew

