

1. Download AUTEK IKEY820 V1.5 UPDATE TOOL from official website or following link:  
<https://drive.google.com/open?id=15nkp-vKNAzJUxkdw6fRrIQGA9uckziKn>

2. Install V1.4 update tool

image	2018/10/26 10:58	文件夹	
Autek Ikey 820 Update Tool V1.4	2018/10/26 10:36	应用程序	4,789 KB

3. Connect IKEY820 to PC with USB (make sure internet is available)

4. Run AUTEK IKEY820 V1.5 Update tool

**Autek Ikey 820 Update Tool V1.4**

**UPDATE SOFTWARE**

SN:       DISK:      

**ACTIVATE TOKENS**

REQ CODE:

ANS CODE:      

**AUTHORIZED FUNCTION**

PLEASE ENTER 18 DIGIT CODE:

    

PLEASE MAKE SURE YOUR PC IS ON INTERNET

5. Input License number and click AUTHORIZE button

**Autek Ikey 820 Update Tool V1.4**

**UPDATE SOFTWARE**

SN:  DISK:

**ACTIVATE TOKENS**

REQ CODE:

ANS CODE:

**AUTHORIZED FUNCTION**

PLEASE ENTER 18 DIGIT CODE:

PLEASE MAKE SURE YOUR PC IS ON INTERNET

6. You IKEY820 is equipped with FORD 2018+ and TOYOTA G and H software