



## **USER MANUAL**

- **CONTENTS**
- (1) Cyclone LED Race Car
- (1) 2.4 GHz Transmitter
- (2) Rechargeable Battery
- (1) USB Charging cable
  - (1) Manual (1) Screwdriver


## FOR MORE INFORMATION

Visit us online at Force1rc.com for product information, replacement parts, and tutorials.

## **OPERATION**

## BATTERY INSTALLATION

# SAFETY INFORMATION




### Forward:

Push the Left and Right Joystick up at the same time to move forward

### Backward:


Push the Left and Right Joystick back at the same time to move backward




### 360° Spins:

Push the Left Joystick forward and the Right Jovstick backward in order to spin to the right.

Push the Right Joystick forward and the Left Joystick backward in order to spin to the left.



# RECHARGEABLE



## **Battery Instructions:**

- 1. Unscrew the battery compartment cover on the back of the RC car.
- 2. Attach the battery according to the diagram above.
- 3. Replace the battery compartment and fasten it shut with the included screwdriver.

### Charging Instructions:

- 1. Attach the battery to the USB cable according to the diagram above.
- 2. Plug the USB end into a Laptop, Power Port or Wall Outlet. Only charge using these methods.

## **TRANSMITTER BATTERY INSTALLATION**



Use 2.1.5V AAA hatteries (Not included)

## Replacing the Remote Transmitter

- 1. Unscrew the battery compartment cover on the back of the remote.
- 2. Remove any exhausted batteries from the compartment.
- 3. Place 2 new 1.5V AAA batteries into the compartment following
- the polarity diagram above. 4. Replace the battery compartment cover and fasten it shut with the included screwdriver.

### IMPORTANT STATEMENT

Please read this manual carefully before operating the RC car. By reading this manual it is assumed you are accepting all content in this user manual.

- Please properly recycle and dispose of old batteries in accordance to local laws and regulations
- · Check all components often and discard if damage is found on plugs and wiring
- This RC car has fast moving parts. Keep hands and body parts away from moving parts and tie hair back before use in order to prevent tangling

If you have any questions about use, operation, technical support, repair, after-sale service, etc. Please contact us at support@force1rc.com.

## WARNING

CHOKING HAZARD Small parts. Not for Children Under 3 Years Old.







### **BATTERY CAUTION**

- Non-rechargeable battery cannot be recharged Do not use different types of batteries
- Load batteries according to proper polarity indication
- Exhausted batteries should be removed from the toy
- The supply terminals should not be short-circuited
- Do not mix new and old batteries.
- Take out batteries when not in use
- Do not over charge the battery
- Do not leave battery unattended while charging
- Keep battery in a cool place do not leave in direct sunlight or exposed to heat














# **BATTERY INSTALLATION**



Power Port



Wall Outlet

## Batteries: