



FOURSEVENS

ATOM
ALR2

OPERATOR'S MANUAL

Model

ATOM ALR2



POWER One CR2 battery



OUTPUT Maximum: 100 lumens
Minimum: 5 lumens



RUNTIME Maximum: 46 hours
Minimum: 2.5 hours

Operation

Operating your Atom is simple. Insert battery with the positive side (+) toward the head. Turn on the Atom by tightening the head. The Atom will initially turn on at low mode; continue turning the head and it will switch to high mode. Once in high mode do not continue to tighten the head or you may damage the Atom. Turn off the Atom by simply loosening the head until it turns off.

The Atom is waterproof to IPX-8 standard. However, do not tighten or loosen the head while underwater or when the Atom is wet.

Did you know that you can convert your Atom into a headlamp? Purchase our optional 360° Headlamp Kit designed especially for our Atoms and Minis at FOURSEVENS.COM or at your favorite FOURSEVENS dealer.

Specifications

Dimensions	Power Source
Length: 1.67 in	One CR2 Battery
Diameter: 0.74 in	Operating Range: 1.0~4.2 V
Weight: 1.05 oz	

Typical Output and Runtimes

Mode	Output (out the front)	Runtime
Low	5 lumens	46 hours
High	100 lumens	2.5 hours

Warranty

FOURSEVENS warrants its products to be free from defects in materials and workmanship. We will repair or replace, at our option, without charge any product or part which is found to be defective under normal use and service within 10 years from the date of purchase with proof of purchase. Such repair or replacement shall be the purchaser's sole and exclusive remedy under this warranty. This warranty does not cover normal maintenance and service and does not apply to any products or parts which have been subject to modification, misuse, abuse, negligence, accident, or improper maintenance or repair by anyone other than FOURSEVENS.

Prometheus Lights
support@darksucks.com
www.darksucks.com