
DW-96011 Staggered Rock Canyon Garden Fountain

TOSCANO INSTRUCTIONS FOR PRODUCT

Thank you for your recent purchase of this Design Toscano hand-crafted garden fountain. We have taken great care to create this piece especially for you. Please review these instructions and assemble this piece with care.



Steps 1-3

- (1) Connect the flexible hose to the pump.
- (2) Connect the light cable to the transformer.
- (3) Slide cover on the fountain body.

Adjust the pump flow rate to achieve the desired effect and to minimize any splashing. Splashing can occur if the flow rate is too high or the feature is too full. The flow rate can be increased or decreased by moving the flow rate control slider on the pump body. Moving the switch towards (+) will increase the flow rate and moving it towards (-) will decrease it.

©Copyright 2021, Design Toscano, Inc.

1.800.525.0733 DESIGNTOSCANO.COM



Steps 4-5

- (4) Fill the reserviour with water and take a note of the level that the water reaches for future reference when topping off.
- (5) Plug in and switch on, after a short while the water will start to flow.

WARNING:

Never turn on the pump before the fountain is full of water. Also do not let the water level fall below the top of the pump as the pump will beome damaged if run without water. Fountain should be placed on a level surface.

