


Top/Bottom

Form/Spacer

NOTE: Print pattern full sized.
Outer pattern is to form the
top and bottom. Inside pattern
is used for the form and spacer

Shaker Large



Shaker Small

