



CONDUIT ROD OPERATING INSTRUCTIONS

Prior to use of equipment ensure all safety requirements have been met then follow instructions as follows.

- Visually inspect both rod and frame to ensure the equipment is suitable for use
- Make sure the rod is threaded through the protective rod guide prior to release of reel brake.
- Release the reel brake to allow the inner frame to move freely
- The rod can now be dispensed from the frame
- If at any time should the operator need to leave the conduit rod the reel brake **must always** be applied to stop the rod free feeding off the frame.
- When returning the rod to the frame ensure rod is threaded through the protective rod guide and the end of the rod situated in the end securing tube.
- The rod can now be fed back onto the frame
- Once all the rod has been returned to the frame secure by tightening the reel brake

It is advised that safety goggles and safety gloves be worn at all times whilst operating the rod.