




REPUBLIC of CROC

# CRYSTALLINE BLOW DRYER


PRODUCT MANUAL



# NAME OF PARTS



# MANUAL



Plug unit into properly grounded power outlet.

- **To turn on, press the Start/Stop button once.**
- To change the temperature / air pressure setting, press the Start/Stop button.
- To turn on the INFRARED, press the INFRARED button on the back.
- **To turn off, press the Start/Stop button for 2 seconds.**

Dry the hair by rotating the dryer over the head.

Keep the dryer a safe distance from scalp to avoid excessive heat exposure or discomfort.

\* After power is turned off, the motor rotates for 1 second due to the protection of the product and the removal of residual heat.

# MEMBRANE DISPLAY

Max blow / Cool



Min blow / Low Heat



Max blow / High Heat



**START**  
**STOP**

**X 1 =**



Bright Red : Max blow / High Heat

**START**  
**STOP**

**X 2 =**



Dull Red : Min blow / Low Heat

**START**  
**STOP**

**X 3 =**



Blue : Max blow / Cool

# **IMPORTANT SAFETY INSTRUCTIONS**

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

**READ ALL INSTRUCTIONS BEFORE USING.  
KEEP AWAY FROM WATER.**

## **DANGER:**

ANY APPLIANCE IS ELECTRICALLY LIVE EVEN WHEN THE SWITCH IS OFF. TO REDUCE THE RISK OF DEATH OR INJURY BY ELECTRIC SHOCK:

- ALWAYS UNPLUG APPLIANCE IMMEDIATELY AFTER USING.
- DO NOT USE WHILE BATHING OR IN THE SHOWER.
- DO NOT PLACE OR STORE APPLIANCE WHERE IT CAN FALL OR BE PULLED INTO A TUB OR SINK.
- DO NOT USE NEAR, PLACE IN OR DROP INTO WATER OR OTHER LIQUID.
- IF AN APPLIANCE FALLS INTO WATER, UNPLUG IT IMMEDIATELY. DO NOT REACH INTO THE WATER.