

PORT-A-FIELD DIY Instructions

Congratulations! You've purchased a unique product that gives you the ability to create your own custom athletic field. The kit includes everything you need including a line cutter, anchors, and plastic hardware used to make corners and ends. The Port-a-Field logos printed on the lines are purposefully printed 2.5 yards apart. Use them to measure and size your lines, creating matching lengths for sidelines and endlines. Now, you truly ...

OWN THE FIELD!



Step 1: Insert one end of the line thru both sides of a slide. Go up through the bottom and then down through the top.



Step 2: Repeat Step 1 with a second slide. Note: A second slide is not required but recommended to function as a "tail manager" for the excess material.



Step 3: Insert the tail end through a ring going down from the top and out the bottom.



Step 4: Go back through both sides of each slide installed in Step 1 & Step 2.



Step 5: Position the ring at the desired location and cinch one slide to the ring. Adjust the second slide as needed to function as a "tail manager", keeping the tail in line with the field.



Step 6: Take one of the steel anchors in the hardware package, insert the flat end of the anchor through the ring and then anchor the ring to the ground at a corner of your area.



Step 7: Walk toward your next point or corner of the playing area you are defining, unreeling the field line as you go. The Port-a-Field logos are 2.5 yards apart. Use them to size your line the number of yards you need. Using the line cutter, cut the line between the last logo you need and the next logo, creating a tail with the excess material beyond your chosen logo. Apply two slides and a ring as before.



Step 8: Create a corner by repeating the process with a second line and attaching both lines to the same single ring. Continue to your next corner, repeating this process until you reach your initial beginning point, completing your field. Use the first anchor for both ends. TIP: To "square" your field, pull the two ends tight at the same time and re-insert your anchor through both rings.



Step 9: RETRIEVEAL: DO NOT REMOVE YOUR CORNER ANCHORS until you reach them while reeling up your field. Use them to provide tension and keep the lines tight as you reel them up.

CS Platinum Sports, LLC 916 Ruby Street Nacogdoches, TX 75961 (800) 268-7552