

WARNING!
ALWAYS CONNECT MACHINE
FRAME TO GROUND AND
CHECK GROUND CONTINUITY
BEFORE OPERATION!
FAILURE TO CONNECT AND CHECK GROUND
COULD RESULT IN INJURY OR DEATH

