

## CARE & MAINTENANCE

1. Once you have finished cleaning your batch of records, discard the used cleaning solution.
2. Unclick the cleaning brushes and press them together over the sink to remove any excess liquid.
3. Rinse all accessories with warm water and set them aside to air dry.
4. Once dry, put all accessories into the machine and reattach the lid for storage.
5. When the cloths become dirty, you can either rinse them with soap and warm water, or at 30°C in a washing machine, without fabric conditioner.

**Need help?** If you require any technical support or advice, please contact us at [support@spincare.co.uk](mailto:support@spincare.co.uk)



# SPINCARE

RECORD CLEANING  
MACHINE



Scan for PDF instructions or visit  
[spincare.co.uk/rcm](http://spincare.co.uk/rcm)

## OVERVIEW

Thank you for purchasing the SPINCARE® record cleaning machine. Please read these instructions carefully as they will allow you to get the best out of your machine.

## BEFORE YOU START

1. Unpack your SPINCARE® record cleaning machine and all accessories from the box.
2. Please wash the supplied microfibre cleaning cloths before use without fabric conditioner. We recommend a maximum temperature of 30°C. Alternatively, you can rinse the cloths with warm water.
3. Ensure you have either distilled or deionised water to fill the sink. We do not recommend using tap water as it can contain impurities and contaminants.
4. We recommend cleaning a low-value record(s) initially whilst you familiarise yourself with the machine.

## CONTENTS

	1 x Record washing sink
	1 x Drying rack (found under the sink)
	2 x Velvet cleaning brushes (pre-fitted)
	2 x 150ml cleaning solution
	2 x Microfibre drying cloths (35cm x 35cm)
	2 x Rollers

## INSTRUCTIONS

### SETUP

1. Remove the lid and drying rack from underneath the record sink.
2. Select the roller position – 7", 10" or 12" (narrowest to widest). The machine is set to 12" by default.
3. The brushes are pre-fitted, but please double-check they are securely clicked into place.
4. Fill the sink with distilled or deionised water to the **MAX WATER** fill line.
5. Add 4 capfuls of record cleaning fluid (approx. 25ml) between the cleaning brushes.

### CLEANING

1. Insert the first record you want to clean into the sink. Slowly rotate the record **CLOCKWISE** 3 times.
2. Slowly rotate the record **ANTI-CLOCKWISE** 3 times.
3. Carefully remove the record from the washer without touching the playing surface and place it into the drying rack.
4. Any excess fluid will drop into the drying rack reservoir. We recommend leaving them to air dry for 5-10 minutes, whilst you clean your other records.
5. Place one of the microfibre cloths on a flat, stable surface. You can also use any soft, lint-free cloth for this step.
6. Place your record onto the cloth.
7. Hold the record in place by gently pressing downwards on the label with your fingertips.
8. Using your other hand, wipe the record clean along the grooves in a circular motion (not across).
9. Once the record is completely dry, put it into an anti-static inner sleeve.
10. Repeat the process above for all the records you want to clean. Each batch of fluid should clean 25-50 records.