



## **R-N2000A Reset Procedure**



## **Soft Reset:**

Hold down the power button on the front panel for 15 seconds. If the problem persists, unplug from the wall, plug it again and repeat.

## **Hard Reset:**

Put the unit into standby by flicking the power switch (front left) off. Then hold down the 'Return/Connect' button, at the same time turn the unit back on with the power switch.

The 'Advanced Menu' will now appear on the display strip.

Navigate this menu by turning the 'Select' jog dial until 'Initialization' is displayed.

Then confirm that option by clicking the 'Select' jog dial.

Next, move the 'Select' jog dial until 'All' is shown on the display.

Complete the reset by powering the unit off with the front mounted power switch.

