

1 ■ EXTENDED IR CODES

Function		Device	Code		XDA-QS5400RK	XDA-AMP5400RK			
Group	Name		Zone	(ID1)			(ID2)		
POWER	POWER	ON	RECEIVER	MAIN	7E-7E	7E-7E80	O	O	
			ZONE2	7E-BA	7E-BA44	O	O		
			ZONE3	7A-ED	7A-ED13	O	O		
			ZONE4	7A-7B	7A-7B85	O	O		
			ALL	7A-1D	7A-1DE3	O	O		
	STANDBY	OFF	RECEIVER	MAIN	7E-7F	7E-7F81	O	O	
			ZONE2	7E-BB	7E-BB45	O	O		
			ZONE3	7A-EE	7A-EE10	O	O		
			ZONE4	7A-7C	7A-7C82	O	O		
			ALL	7A-1E	7A-1EE0	O	O		
	SLEEP	ON	RECEIVER	MAIN	7E-1669	7E-1668	O	-	
			ZONE2	7E-1768	7E-1769	O	-		
			ZONE3	7E-1867	7E-1866	O	-		
			ZONE4	7E-1966	7E-1967	O	-		
			ALL	7E-1A65	7E-1A64	O	-		
		OFF	RECEIVER	MAIN	7E-1B64	7E-1B65	O	-	
			ZONE2	7E-1C63	7E-1C62	O	-		
			ZONE3	7E-1D62	7E-1D63	O	-		
			ZONE4	7E-1E61	7E-1E60	O	-		
			ALL	7E-B3	7E-B34D	O	-		
120 min	RECEIVER	ALL	7E-B4	7E-B44A	O	-			
90 min	RECEIVER	ALL	7E-B5	7E-B54B	O	-			
60 min	RECEIVER	ALL	7E-B6	7E-B648	O	-			
30 min	RECEIVER	ALL	7E-B7	7E-B749	O	-			
INPUT	USB	RECEIVER	MAIN	7F01-720D	7F01-720C	O	-		
		ZONE2	7F01-730C	7F01-730D	O	-			
		ZONE3	7F01-740B	7F01-740A	O	-			
		ZONE4	7F01-7A05	7F01-7A04	O	-			
		RECEIVER	MAIN	7A-55	7A-55AB	O	-		
	BUS-IN		RECEIVER	ZONE2	7A-D8	7A-D826	O	-	
			ZONE3	7A-F0	7A-F00E	O	-		
			ZONE4	7A-7D	7A-7D83	O	-		
			RECEIVER	MAIN	7F01-3F	7F01-3FC1	O	-	
	NET	TOGGLE	RECEIVER	ZONE2	7F01-40	7F01-40BE	O	-	
			ZONE3	7F01-41	7F01-41BF	O	-		
			ZONE4	7F01-49	7F01-49B7	O	-		
			RECEIVER	MAIN	7F01-6C13	7F01-6C12	O	-	
	SUB INPUT	SERVER	RECEIVER	ZONE2	7F01-6D12	7F01-6D13	O	-	
			ZONE3	7F01-6E11	7F01-6E10	O	-		
			ZONE4	7F01-7807	7F01-7806	O	-		
			RECEIVER	MAIN	7F01-6F10	7F01-6F11	O	-	
		NET RADIO		RECEIVER	ZONE2	7F01-700F	7F01-700E	O	-
				ZONE3	7F01-710E	7F01-710F	O	-	
				ZONE4	7F01-7906	7F01-7907	O	-	

Function		Device	Code		XDA-QS5400RK	XDA-AMP5400RK		
Group	Name		Zone	(ID1)			(ID2)	
INPUT	SUB INPUT	Rhapsody or Napster * U, G models	RECEIVER	MAIN	7F01-750A	7F01-750B	O	-
			ZONE2	7F01-7609	7F01-7608	O	-	
			ZONE3	7F01-7708	7F01-7709	O	-	
			ZONE4	7F01-7B04	7F01-7B05	O	-	
		Pandora * U, A models	RECEIVER	MAIN	7F01-85FA	7F01-85FB	O	-
			ZONE2	7F01-86F9	7F01-86F8	O	-	
			ZONE3	7F01-87F8	7F01-87F9	O	-	
			ZONE4	7F01-88F7	7F01-88F6	O	-	
		Sirius XM * U model	RECEIVER	MAIN	7F01-81FE	7F01-81FF	O	-
			ZONE2	7F01-82FD	7F01-82FC	O	-	
			ZONE3	7F01-83FC	7F01-83FD	O	-	
			ZONE4	7F01-84FB	7F01-84FA	O	-	
	Spotify	RECEIVER	MAIN	7F01-8DF2	7F01-8DF3	O	-	
		ZONE2	7F01-8EF1	7F01-8EF0	O	-		
		ZONE3	7F01-8FF0	7F01-8FF1	O	-		
		ZONE4	7F01-90EF	7F01-90EE	O	-		
	JUKE * G model	RECEIVER	MAIN	7F01-95EA	7F01-95EB	O	-	
		ZONE2	7F01-96E9	7F01-96E8	O	-		
		ZONE3	7F01-97E8	7F01-97E9	O	-		
		ZONE4	7F01-98E7	7F01-98E6	O	-		
Radiko * Not for service	RECEIVER	MAIN	7F01-9AE5	7F01-9AE4	-	-		
	ZONE2	7F01-9BE4	7F01-9BE5	-	-			
	ZONE3	7F01-9CE3	7F01-9CE2	-	-			
	ZONE4	7F01-9DE2	7F01-9DE3	-	-			
Qobuz * G model	RECEIVER	MAIN	7F01-9EE1	7F01-9EE0	O	-		
	ZONE2	7F01-9FE0	7F01-9FE1	O	-			
	ZONE3	7F01-A0DF	7F01-A0DE	O	-			
	ZONE4	7F01-A1DE	7F01-A1DF	O	-			
AirPlay	RECEIVER	MAIN	7F01-91EE	7F01-91EF	O	-		
	ZONE2	7F01-92ED	7F01-92EC	O	-			
	ZONE3	7F01-93EC	7F01-93ED	O	-			
	ZONE4	7F01-94EB	7F01-94EA	O	-			
MC Link	RECEIVER	MAIN	7A-D5AA	7A-D5AB	O	-		
	ZONE2	7A-D6A9	7A-D6A8	O	-			
	ZONE3	7A-D7A8	7A-D7A9	O	-			
	ZONE4	7A-D8A7	7A-D8A6	O	-			
VOLUME	VOLUME	UP	RECEIVER	MAIN	7A-1A	7A-1AE4	O	-
			ZONE2	7A-DA	7A-DA24	O	-	
			ZONE3	7A-FD	7A-FD03	O	-	
			ZONE4	7A-2B	7A-2BD5	O	-	
	DOWN	RECEIVER	MAIN	7A-1B	7A-1BE5	O	-	
		ZONE2	7A-DB	7A-DB25	O	-		
		ZONE3	7A-FE	7A-FE00	O	-		
		ZONE4	7A-2C	7A-2CD2	O	-		

7

Function			Device	Code		XDA-QS5400RK	XDA-AMP5400RK		
Group	Name			Zone	(ID1)			(ID2)	
VOLUME	MUTE	TOGGLE	RECEIVER	MAIN	7A-1C	7A-1CE2	O	O	
				ZONE2	7A-DC	7A-DC22	O	O	
				ZONE3	7A-FF	7A-FF01	O	O	
				ZONE4	7A-2D	7A-2DD3	O	O	
		ON (FULL)	RECEIVER	MAIN	7E-A2	7E-A25C	O	O	
				ZONE2	7E-A0	7E-A05E	O	O	
				ZONE3	7E-26	7E-26D8	O	O	
				ZONE4	7E-0C73	7E-0C72	O	O	
		ON (-40dB)	RECEIVER	MAIN	7E-631C	7E-631D	O	-	
				ZONE2	7E-641B	7E-641A	O	-	
				ZONE3	7E-651A	7E-651B	O	-	
				ZONE4	7E-6619	7E-6618	O	-	
		ON (-20dB)	RECEIVER	MAIN	7E-DF	7E-DF21	O	-	
				ZONE2	7E-2956	7E-2957	O	-	
				ZONE3	7E-2A55	7E-2A54	O	-	
				ZONE4	7E-2B54	7E-2B55	O	-	
	OFF	RECEIVER	MAIN	7E-A3	7E-A35D	O	O		
			ZONE2	7E-A1	7E-A15F	O	O		
			ZONE3	7E-66	7E-6698	O	O		
			ZONE4	7E-0D72	7E-0D73	O	O		
	PROGRAM	ENHANCER	ON	RECEIVER	MAIN	7E-D8	7E-D826	O	-
					ZONE2	7E-B9C6	7E-B9C7	O	-
					ZONE3	7E-BBC4	7E-BBC5	O	-
					ZONE4	7E-BEC1	7E-BEC0	O	-
			OFF	RECEIVER	MAIN	7E-D9	7E-D927	O	-
					ZONE2	7E-BAC5	7E-BAC4	O	-
					ZONE3	7E-BCC3	7E-BCC2	O	-
					ZONE4	7E-BFC0	7E-BFC1	O	-
TRIGGER		MANUAL ON	RECEIVER	MAIN	7E-3F40	7E-3F41	O	-	
				ZONE2	7E-413E	7E-413F	O	-	
				ZONE3	7E-52	7E-52AC	O	-	
				ZONE4	7E-C0BF	7E-C0BE	O	-	
		MANUAL OFF	RECEIVER	MAIN	7E-403F	7E-403E	O	-	
				ZONE2	7E-423D	7E-423C	O	-	
				ZONE3	7E-53	7E-53AD	O	-	
				ZONE4	7E-C1BE	7E-C1BF	O	-	
OPERATION		PAUSE	RECEIVER	MAIN	7F01-67	7F01-6799	O	-	
				ZONE2	7F01-87	7F01-8779	O	-	
				ZONE3	7F01-A7	7F01-A759	O	-	
				ZONE4	7F01-C7	7F01-C739	O	-	

Function			Device	Code		XDA-QS5400RK	XDA-AMP5400RK	
Group	Name			Zone	(ID1)			(ID2)
OPERATION	PLAY		RECEIVER	MAIN	7F01-68	7F01-6896	O	-
				ZONE2	7F01-88	7F01-8876	O	-
				ZONE3	7F01-A8	7F01-A856	O	-
				ZONE4	7F01-C8	7F01-C836	O	-
	STOP		RECEIVER	MAIN	7F01-69	7F01-6997	O	-
				ZONE2	7F01-89	7F01-8977	O	-
				ZONE3	7F01-A9	7F01-A957	O	-
				ZONE4	7F01-C9	7F01-C937	O	-
	SKIP	SKIP-	RECEIVER	MAIN	7F01-6C	7F01-6C92	O	-
				ZONE2	7F01-8C	7F01-8C72	O	-
				ZONE3	7F01-AC	7F01-AC52	O	-
				ZONE4	7F01-CC	7F01-CC32	O	-
SKIP+		RECEIVER	MAIN	7F01-6D	7F01-6D93	O	-	
			ZONE2	7F01-8D	7F01-8D73	O	-	
			ZONE3	7F01-AD	7F01-AD53	O	-	
			ZONE4	7F01-CD	7F01-CD33	O	-	