



YAMAHA®

NSNSW100 Reset Procedure



On the rear panel, press 'STANDBY / ON' to put the unit into standby.

While holding 'CONNECT', press 'STANDBY / ON'.

When the status indicator flashes (located on top), release 'CONNECT'.