



## SR-X50A Reset Procedure



1 :  
Turn off the sound bar.

2 :  
While holding down + on the sound bar, press the power button until all indicators flash.  
The settings of the sound bar are now initialized.

### NOTE

The connection information with the subwoofer will remain even if the settings of the sound bar are initialized.