


Yamaha TW-E5B


Initializing (performing a factory reset)

This will restore all of the earbud settings to their factory defaults. The information for devices registered (paired) will be deleted.


1. Remove earbuds (L) and (R) from the charging case.
 - The indicators light up blue for one second.



2. Hold down the function key and the + (plus) key for about seven seconds to turn the power off.
 - Make sure that the indicator lights up as shown below.



3. After the power turns off, hold down the function key and the + (plus) key for 10 seconds.
 - Make sure that the indicator lights up as shown below.



4. Place earbuds (L) and (R) in the charging case.
 - The earbuds are now initialized (factory reset).