Mozee e285 Sled Instructions

- Insert the Verifone e285 into the sled, ensuring it is fully seated.
- Place the included long screw into the bottom hole in the back of the sled so that it also extends into the back of the payment device.
- Tighten the screw with a Phillips screwdriver. [Do not over tighten].
- To remove the payment device, remove the screw and slide the e285 from the sled.

