




Picnic Table Assembly Instructions (Models M-400, M-500, M-600, M-700, M-800)


NOTE: Please check contents and read directions carefully before assembly. If any items are missing or damaged, please contact the store in which you purchase it from and they *will correct the problem as promptly and as efficiently as possible*. Also, checking or cracking of the logs is a *natural part of the drying aspect of cedar. This does not affect the structural integrity of the wood.* This natural occurrence enhances the rustic beauty of the product.



Picnic Table Components

- (1) Pre-Assembled Table Top (A)
- (2) Leg Units (B)
- (2) Seat Boards (C)
- (2) Table Braces (D)
- 5" Lag Bolts (F) *see attached hardware sheet*
- 3 1/2" Lag Bolts (H) *see attached hardware sheet*
- 1/4" Washers (W) *see attached hardware sheet*
- 3/8" Washers *see attached hardware sheet*
- 4" Lag Bolts (G) *see attached hardware sheet*

Tools Required: Electric Drill, Socket Wrench, or Impact Wrench
1/2" Socket & 10mm Socket, Measuring Tape, padded surface




Step 1: Place table top (A) upside-down on a padded surface. Next, center and place the leg units (B) to the inside of the large table underlays, with notches on legs resting on underlay. Secure leg units to the underlays with 5" lag bolts (F) through pre-drilled holes (as shown).

Large Table Underlay

Underside of Table


Notch facing this out




Underside of Table

Middle Table Underlay

Step 2: Attach table braces (**D**) the middle table underlay. Secure angled end of table brace to table underlay using 3 1/2" lag bolt (**H**) (as shown). Be sure that the angled end is slightly off-center on the underlay in order to make room for the other table brace. *Note: Use a 1/4" washer (**W**) when inserting each 3 1/2" lag bolt (**H**).*



Step 3: Secure the table brace (**D**) to the leg unit (**B**) with a 4" lag bolt (**G**), placed through the pre-drilled hole on the leg unit (as shown). *Note: Use a 1/4" washer (**W**) when inserting each 4" lag bolt(**G**).*



Manufacturing tip: After table is assembled, pick up table from each end and forcefully set on ground. This will help to level table.

You may need two people to attach seat boards.

Step 4: Place bottom of seat boards (**C**) underneath seat support poles (as shown). Move seat board approx. 1" out over the seat support poles, and align with table top to ensure correct proximity. Secure the seat boards to the seat support poles using 3 1/2" lag bolts (**H**) through pre-drilled holes. *Note: Use a 1/4" washer (**W**) when inserting each 3 1/2" lag bolt(**H**).*

Thank you for your Moon Valley purchase and we hope that you enjoy your Picnic Table. To view other Moon Valley products, please contact your local dealer or visit us at www.moonvalleycedarworks.com.






www.moonvalleycedarworks.com March 2012. Do not let children play with plastic bag.

Hardware Sheet for M-400 M-500, M-600, M-700 and M-800

NOTE: Please check contents and read directions carefully before assembly. If any items are missing or damaged, *do not take the product back to the store. Call Moon Valley customer service at 313-766-4950 and we will correct the problem as promptly and as efficiently as possible.*



***4 x 3/8" Washer add to 5" Lag Bolt**

Moon Valley Cedar Works
12717 Marlin Drive, Redford, Mi 48239
Phone: (313) 766-4950 Fax: (313) 766-4953
www.moonvalleycedarworks.com
Do not let children play with plastic bag.



Moon Valley Furniture Care, Maintenance & Warranty Sheet

Stained Furniture

Moon Valley's linseed oil-based stain has a uniform color consistency, seals out moisture, protects against mildew and blocks the damaging effects of ultra-violet light. It also penetrates the wood in order to help prevent discoloration. In order to maintain the stained items, it is recommended to wash and dry the areas then re-apply a coat of stain. Moon Valley supplies their stain in quart cans which can be purchased from your local dealer.

Varnished Furniture

Varnished Moon Valley furniture is dipped piece by piece in a sealer that provides uniform color consistency, seals out moisture, protects against mildew and blocks the damaging effects of ultra-violet light. It is then topped off with 2 coats of marine spar varnish for a glossy look. This varnish is specially formulated for outdoor use and should be maintained once a year. To do this, lightly sand the item using a medium-grit sandpaper (100 to 120-grit) or steel wool. Be sure that the surface is clean and **completely dry** before beginning the process. Next, apply a coat of the new varnish, usually by brushing. Let dry as needed and repeat again for extra protection against weathering. Moon Valley supplies their varnish in quart cans which can be purchased from your local dealer.

Unfinished Furniture

Moon Valley products are made from white cedar. Cedar is naturally more resistant to weather decay and insect damage than other types of wood, so you can simply leave it as is. Over time, it will turn a silvery-gray color which gives it a rustic, aged look. However, there are finishing options such as using a water sealer, varnish, stain, or paint based on customer preference. Before undertaking any of these options, please refer to our website for suggested finishing steps.

Cracking or Checking of the Logs

You may notice some cracking or *checking* of the logs on your furniture, which is completely natural and necessary for cedar left in log form. This **does not** compromise the integrity or strength of the product in any way. Many times, it enhances the natural rustic beauty of the furniture. For more information on cracking and checking, please visit our website (www.moonvalleyrustic.com).

Winter Storage

If it is not possible for you to store the furniture indoors for the winter, simply stand or lean your picnic table (preferably on blocks) against your house or garage. This will help lessen the effects of weathering by not allowing snow or water to accumulate on the flat surfaces of the furniture. **Do not** cover with plastic or place the table upside down on the ground, as this will trap moisture against surfaces and cause damage. If you choose to cover the furniture, be sure that the cover is breathable and allows for proper air ventilation.

Safety

Although your furniture has been constructed for greater strength and stability, it should be checked periodically for looseness or wear. Regularly inspect joints, bolts, and hooks and hardware if necessary. These items can be purchased from your local dealer, or by using the below contact information.

Thank you for purchasing a Moon Valley product. We have made every effort to ensure that you are satisfied with your selection. To insure prompt and correct handling of any errors, missing parts, or to answer any questions, please call (313) 766-4950. All replacement part orders will be filled as quickly as possible.

Limited Warranty

Moon Valley warrants its products to be free from manufacturing defects for a period of one year after its purchase. Proof of purchase must be provided. Finish is not included under the limited warranty. Any defects must be promptly reported to Moon Valley and the defective part will be replaced without charge.

Disclaimer of Warranties

This limited warranty is made in lieu of all other warranties, express or implied, including implied warranties of merchantability and/or fitness for a particular purpose.

Limitation of Liability

Moon Valley liability is limited to the replacement of defective parts, as set forth in its limited warranty. Moon Valley shall not be liable for any incidental or consequential damage, including without limitation, damages for personal injury, death, or loss of profits.

Do not let children play with plastic bags