

PROPER GUNWALE ASSEMBLY

The end of all four gunwale caps should be on the inside of the canoe, under the straps.



Black piece is under the white fold and the strap.



Contact the MyCanoe team if you have any questions.
support@oricanoe.com | oricanoe.com