



Connector MAIN

2	1
4	3
6	5
8	7
10	9
12	11
14	13
16	15
18	17
20	19
22	21
24	23

Connector AUX

16	14	12	10	8	6	4	2
15	13	11	9	7	5	3	1

