



EXCLUSIVE BRANDS ONLINE
ASSURED RELIANCE



Before you get started, please make sure to read the User Manual.

It is highly recommended to start your first i-Glide™ experience with a friend. Having a spotter during initial use will increase your confidence and help you become acclimated to your i-Glide™. Always wear the proper safety gear before operating. ENJOY YOUR i-Glide™!

PLEASE NOTE:

- The original iGlide™ is an Intelligent Personal Mobility Device.
- Before riding, please read the User Manual carefully, and follow all Safety Precautions.
- Improper use of this product can lead to property damage, serious bodily injury, and/or death.
- The information in this User Manual will help you better understand, enjoy and maintain your iGlide™.
- For more information or questions regarding the i-Glide™, please contact:
✓ info@exclusivebrandsonline.co.za

Table of Contents

| | |
|---------------------------------------------------------|--|
| 1. Product Overview..... | |
| 1.1 General Information..... | |
| 1.2 What You Need To Know..... | |
| 1.3 WARNING..... | |
| 2. Product Description..... | |
| 2.1 Description of I-Glide™..... | |
| 2.2 Description of I-Glide Components™..... | |
| 3. Operating Principles | |
| 3.1 How I-Glide™ Works..... | |
| 3.2 READ THE FOLLOWING INSTRUCTIONS CAREFULLY | |
| Step 1-Getting Started..... | |
| Step 2-Checking the Display Board..... | |
| Step 3-Charging your I-glide™..... | |
| Step 4-Safety Gear..... | |
| Step 5-Stepping On..... | |
| Step 6-Staying Balanced..... | |
| Step 7-Riding your I-glide™..... | |
| Step 8-The Dismount..... | |
| 4. Special Functions..... | |
| 4.1 Special Functions -Recalibrating your I-glide™..... | |
| 5. I-glide™ Safety Precautions– MUST READ..... | |
| 6. Weight and Speed Limitations..... | |
| 7. Operating Range..... | |
| 8. Battery Information and Specifications..... | |
| 9. Charging your I-glide™..... | |
| 10. Safety Alerts..... | |
| 11. Inspection, Maintenance, and Storage..... | |
| 12. I-glide™ Specifications and Packing list..... | |

1.Product Overview

1.1 General Information

The original I-Glide is an Intelligent Personal Mobility Device. This device is an intuitive, technologically advanced solution that provides the user personal transportation.

Using the latest technology and production processes, each I-Glide undergoes strict testing for quality and durability. With its portable design, ease of use, range, and low carbon footprint, the I-Glide is the Ultimate Last Mile Solution.

You no longer have walk around, our Estate Cart is specifically designed with it low noise electronic technology for Golf Course, Estates or private property and/or farm use.

1.2 What You Need to Know

Before you first experience your I-Glide, please read the USER MANUAL thoroughly and learn the basics to ensure your safety and the safety of others. The most important thing to do is stay relaxed and confident.

Please follow the detailed directions outlined in the USER MANUAL in Section 3 under Operating Principles.

1.3 WARNING

Failure to follow the basic instructions and safety precautions listed in the USER MANUAL, can lead to damage to your I-glide which can void your warranty, other property damage, serious bodily injury, and even death.

2. Product Description

2.1 Description of I-glide™

The I-glide is a technologically advanced Personal Mobility Device. It has four wheels that balance and transport the user using battery powered motors. The I-glide can move forwards, backwards, turn in either direction or turn in place.

2.2 Description of I-glide™ Components:

The Estate Cart is easy to use with its added components such as key start, hooter, forward and reverse driving capability. With the battery built in, you can simply plug the charger in, charge your Estate Cart and start using.

3. Operating Principles

3.1 How I-glide™ Works

The device also uses an intelligent control system to drive the motors.

The I-glide has a built-in inertia dynamic stabilization system that can help assist with balance when moving forward and backwards, but not while turning.

3.2 PLEASE READ THE FOLLOWING INSTRUCTIONS CAREFULLY

Step 1: Getting Started –Fully charge your Estate Glider for 12 hours before its first use.

The charging port is located behind the front seat at the bottom.

Step 2:

- i) First Turn On the Key: Checking the Display Board – located at the right-hand side of the steering column of your I-Glide. The I-glide should power on and display a battery indicator. The Battery indicator light should be lit, indicating there is power to the device.
- ii) On top of the Estate Cart steering column, in the center, there is a button to switch on the headlights. “I” meaning on and “O” meaning off.
- iii) On the left of the headlight button is an Indicator button for the flickers, left and right.
- iv) On the right-hand side is a button to control the wipers.
- v) In the center of the console on top is a round button which controls speed, for various speed settings.
- vi) On the panel in the middle at the bottom, there are two buttons:
 - (1) One green button for the Horn
 - (2) One button for forward and reverse gear. “F” for Forward and “R” for reverse.
- vii) Upon the right-hand side handle of the steering wheel is the accelerator. Turn inwards to accelerate. (To deactivate the brake, pull the hand-brake inwards and pull then throttle, then release the hand brake in one action.)
- viii) At your right bottom side, is a radio control unit, for radio and USB insert.
- ix) At the middle on the floor below the steering wheel, is a Brake to brake with.
- x) On the right-hand side of the front seat is a hand brake to activate when not in use. Pull upwards to activate the hand brake and downwards to release the hand brake.
- xi) The batteries are located below the front seat. The key of the Cart, can be used to lock and unlock this space. (Please do not tamper or change the batteries as these batteries are specifically manufactured for the spec of this car.) Should you require any assistance or service, it is recommended to contact service@exclusivebrandsonline.co.za for assistance from our designated team of qualified staff to assist. Any tempering, change of batteries may void the manufacturing warranty if not done and approved by an iGlide technician.

Step 3: Charging your I-Glide - Make sure the I-glide is fully charged before your initial use (a complete cycle of twelve hours). For charging instructions, please follow details in Section 8 under Battery and Charging Specifications.

Step 4: Safety Gear - Wear all proper safety gear, including, but not limited to a helmet, knee pads, elbow pads, and wrist guards according to your own discretion.

Step 5: Climbing off your Estate Cart: Come to a complete stop, switch off your Estate Cart and activate the hand brake.

Step 6: Added benefits. There is a storage compartment that can be locked and unlocked located at the front of your estate cart, Two holders within then cart below the steering wheel and one at the back of the Estate Cart.

4. I-GLIDE™ SAFETY PRECAUTIONS –MUST READ



FAILURE TO FOLLOW ANY OF THE FOLLOWING SAFETY PRECAUTIONS CAN AND MAY LEAD TO DAMAGE TO YOUR I-GLIDE, VOID YOUR MANUFACTURER WARRANTY, LEAD TO PROPERTY DAMAGE, CAUSE SERIOUS BODILY INJURY, AND CAN LEAD TO SERIOUS INJURY/DEATH.

1. Please wear all appropriate safety and protective gear as previously mentioned in the User Manual (Section 3) before operating the I-glide.
2. Make sure to wear comfortable clothes and flat closed toe shoes when operating your I-glide.
3. Please carefully read the User Manual, which will assist in explaining the basic working principles and provide tips on how to best enjoy your I-glide experience.
4. ***Do not try to open or modify your I-glide, as doing so will void your manufacturer warranty, and may cause failure to your device leading to serious bodily injury or death.***
5. Do not use the I-glide to place yourself or anyone else and their property in danger.
6. Do not operate the I-glide while under the influence of drugs and/or alcohol.
7. Do not operate the I-glide when you are restless or sleepy.
8. Use your best judgment to keep yourself out of dangerous situations with your I-glide.
9. Do not ride your I-glide off of curbs, ramps, or attempt to operate in a skate park, empty pool, or in any way similar to a skateboard or scooter.
10. Do not turn sharply, especially at high speeds.
11. Do not continuously ride in circles in one place, it will cause dizziness and you will fall and injure yourself.
12. Do not abuse your I-glide, doing so can damage your unit and cause failure to the operating system leading to injury and may void your manufacturing warranty.
13. Do not drive in or near puddles of water, mud and wet sand.
14. The I-glide can be used on paved/tar roads; grass and more rugged terrains.
15. Do not ride in inclement weather: snow, rain, hail, sleet, on icy roads or in extreme heat.
16. Do not ride in or near pools or other large bodies of water.
17. Do not attempt to ride over bumps or objects greater than ½ inch at high speeds.
18. PAY ATTENTION- look at where you are riding and be cognoscente of the road conditions, people, places, property and objects around you.
19. Do not operate the I-glide in crowded areas.
20. Operate your I-glide with extreme caution when indoors, especially around people, property, and narrow spaces like doorways and other narrow spaces.
21. Operate your I-glide with extreme consideration for people and property at all times.
22. Do not operate the I-glide while talking, texting, or looking at your phone.
23. Do not ride your I-glide where it is not permitted.
24. Do not ride your I-glide near motor vehicles or on public roads.
25. Women who are pregnant or who may become pregnant should operate the I-glide with extreme caution.

26. Young children and the elderly should not operate the I-glide without proper instruction and with extreme caution.
27. At higher speeds, always take into consideration longer stopping distances.
28. Do not attempt to jump on or off your I-glide.
29. Do not attempt any stunts or tricks with your I-glide.
30. Do not ride the I-glide near or over potholes, cracks or hazardous objects.
31. Do not exceed the maximum or minimum weight limits.
32. Do not step on the fenders of the I-glide.
33. Avoid driving the I-glide in unsafe places, including near areas with flammable gas, steam, liquid, dust, fiber, which could cause fire and explosion accidents.
34. Do not Switch you i-Glide on when on Charge as this can cause damage to the battery.
35. Follow all of the state, local, and federal laws in your respective jurisdiction regarding operation of the I-glide or similar products.
36. Enjoy your I-glide safely and responsibly.

If you have any questions and/or concerns, or if you would like more information on safety tips, please feel free to contact the EBO team and visit our website for more information and tips on how to best enjoy your I-glide experience.

www.exclusivebrandsonline.co.za

6. Weight and Speed Limitations

PLEASE NOTE- Speed and Weight Limits are set for your own Safety. Please do not exceed the limits listed in the User Manual.

1.1 Weight Restrictions:

1.1.1 Maximum Weight: 250 kg.

1.2 Speed Limits:

1.2.1 Maximum Speed in Standard Operating Mode: up to 50 km/h

7. Average Operating Range

Please note the I-glide can travel a distance on average between 40-70 km on a fully charged battery in ideal conditions. The following are some of the major factors that will affect the operating range of your I-glide.

- ✓ Terrain: A smooth, flat surface will increase your driving distance, while driving uphill, as well as rough or uneven terrain will reduce your distance significantly.
- ✓ Weight: The weight of the user can affect driving distance; a lighter user will have further range than a heavier user. Ambient temperature: Please ride and store the I-glide under recommended temperatures, which will increase driving distance; battery life, and overall performance of your I-glide.
- ✓ Maintenance: Reasonable battery charging and maintenance will increase the distance. Overcharging the battery can reduce range.
- ✓ Speed and Driving Style: Maintaining a moderate speed will increase your distance; while travelling at high speeds for extended periods, frequent starts, stops, idling, along with frequent acceleration and deceleration will reduce your overall distance.

8. Battery Information and Specifications

This section is intended to provide you basic information about your battery and charger. Please read this section carefully to ensure you for user safety and to prolong the life of your battery, as well as improve battery performance, please follow these instructions:

1. Battery Power:

The Green LED light indicates the I-Glide is charged. When the I-glide is at less than 10% battery capacity, please stop operating your I-glide and charge your battery 5-8 hours (depending on the battery life left) utilizing the charger that you received in your I-glide package. To fully recharge your battery please follow the instructions under Charging your I-glide.

2. Battery Specifications:

| |
|----------------------------------|
| Content Parameters |
| Battery: Lead-Acid |
| Charging time: 2-3h |
| Voltage: 60V 20aH |
| Working Temperature: 10°- 50° |
| Charging Temperature: -15°-50° |
| Storage Temperature: -20° -50° |
| Utilizing temperature: -15° -50° |

3. BATTERY WARNING:

Failure to follow the Safety Precautions listed in the Battery Warning could lead to serious bodily injury and death. Seek immediate medical attention if you are exposed to any substance that is emitted from the battery.

Do not attempt to modify, change, or replace your battery. Do not use your I-glide if the battery begins to emit odor, overheats, or begins to leak. Do not touch any leaking materials, or breathe fumes emitted. Do not allow children and animals to touch the battery. The battery contains dangerous substances, do not open the battery, or insert anything into the battery. Please only use the charger provided by EBO. Do not attempt to charge the I-glide if the battery has discharged or emitted any substances. In that case, the battery should be abandoned for safety. Please follow all local, state and federal laws in regards to recycling, handling and disposing of Lead-Acid batteries. The I-glide should only be shipped in its original packaging. Do not throw away your box as you need your I-glide packaging for future use. Do not switch the Estate Glider on whilst charging.

9. Charging your I-glide™

Step 1: Open the battery port cap located behind the front seat at the bottom.

Step 2: Plug the charger into the wall socket, then connect the cable with the power supply, make sure the light on the charger is lit GREEN.

Step 3: Connect the charging cable into the charging port of the I-glide. The indicator light on the charger should change to RED, indicating that your I-glide is now being charged. When the RED indicator light on your charger turns to GREEN, then your I-glide is fully charged.

Step 4: Please unplug the charger from your I-glide and from the power outlet when fully charged. Please do not leave the charger plugged into the wall socket or into the car for an extended period of time as this can/may cause damage to the battery and or the charger by overcharging and or power surges, lightning etc.

Batteries warranty as per warranty terms and conditions. Battery warranties will be covered by the test outcome of the battery if it is a manufacturing defect. Please avoid under- or over-charging as this can cause damage to the battery which will not be covered by the warranty.

Important Notes About Charging

- ✓ If the GREEN light on your charger does not turn RED when you plug it into your I-glide, it could mean you have to check the cables to ensure you have a proper connection; or that your I-glide is already fully charged.
- ✓ Do not overcharge, as this will affect the life of the battery.
- ✓ The best charging temperatures are between -15° -50°
- ✓ Extreme cold and extreme heat will prevent your battery from charging fully.
- ✓ Make sure to unplug your charger before climbing on or operating your I-glide, as this can be very dangerous.
- ✓ Use only the I-glide charger that you received in your box. Please do not use any other charger. Should your charger no longer work, you can purchase a new I-Glide charger from us.
- ✓ Please keep your charger unplugged from the wall socket at all times when not in use to avoid power surges, lightning etc. Chargers are not covered by the manufacturing warranty as it is a perishable item that can malfunction due to multiple unforeseen circumstances.

NOTE- Only the indicator light on the charger will tell you the status of the battery during charging.

10. Safety Alerts

During operation, if there is a system error or illegal operation performed with your I-glide, the system cannot enter normal operation, the Estate Cart will shut down for safety.

The following are common occurrences where you will hear the Safety Alerts; these notices should not be ignored, but appropriate action be taken to correct any illegal operation, failure or errors.

- ✓ Prohibited riding surfaces (Ex. High volume water; liquid or mud.)
- ✓ Battery voltage is too low.
- ✓ The device is still charging.
- ✓ Overheating, motor temperature is too high.
- ✓ System enters protection mode, the alarm indicator will light up and buzzer will alarm (this typically occurs when the battery is about to die).
- ✓ When the battery level has depleted below protection mode, the I-glide engine will power off after 15 seconds.
- ✓ While sustaining a high discharge current during operation (such as driving up a steep slope for a long period of time), the I-glide engine will power off after 15 seconds.
- ✓ The Estate Cart might enter safe mode by not wanting to drive in general conditions as this is a safety measurement set in place for the cart to not accidentally move when touching the accelerator. You can then re-activate driving by holding the hand brake and activating the accelerator in one motion.

11. Inspection, Maintenance, and Storage

Your I-glide requires routine inspection and maintenance. This chapter describes maintenance steps and important operating tips.

Before you perform the following operations, ensure the power and charging cable is disconnected.

1. Inspecting and cleaning your I-Glide:

- ✓ Disconnect the charger and turn off your I-glide.
- ✓ Routinely check the body of the I-glide and tires for damage or excessive wear.
- ✓ Avoid using water or other liquids and cleaners on the I-glide for cleaning.
- ✓ The I-glide is IP 54 rated. It can withstand a light splash of water, however if water or other liquids seep into the device, it will cause permanent damage to the internal electronics.
- ✓ Wet a clean cloth with clean soapy water, rinse the cloth thoroughly, and wipe the body of the I-glide making sure that water does not get into the power button, charging port, the foot mats, or tires.

2. Storing your I-glide™

- ✓ Fully charge your battery before storing.
- ✓ If you are storing your I-glide for an extended period of time, please fully charge your I-glide regularly to keep the battery cells active.
- ✓ If the ambient temperature of the storage location is below -20°, please do not charge. You must bring the I-glide into a warmer environment before charging.

- ✓ To prevent dust from getting into your I-glide, try wrapping it or sealing it. We do also sell covers for added protection.
- ✓ Store your I-glide indoors, in a dry and suitable temperature.

NOTE -Users who dismantle the I-glide™. It will forfeit their right of warranty.

Packing List

1. 1x I-glide
2. 1x Charger

13. Thank You

Thank you for the purchase of your new I-glide™, and thank for taking the time to read the User Manual. We trust that the information that you obtained from this manual will help you safely operate, maintain and enjoy your I-glide for years to come. We appreciate your consideration and sincerely hope you enjoy and share your I-glide experience with all of your friends, family members, and loved ones.

Thank you and welcome to the I-glide™ movement!