


Microphone



Micro SD Card Slot

Charging Indicator LED


Micro USB Charging Port

**Inside The Box:
Microboom Speaker
USB Charging Cable
Necklace**

bumpboxx®

**Instruction Manual:
Bumpboxx Microboom**

Microboom



LIMITATION OF LIABILITY

THE MAXIMUM LIABILITY OF BUMPBOXX UNDER THIS LIMITED WARRANTY IS EXPRESSLY LIMITED TO THE LESSER OF THE PRICE YOU HAVE PAID FOR THE PRODUCT OR THE COST OF REPAIR OR REPLACEMENT OF THAT PRODUCT OR ANY COMPONENT OR PART THAT MALFUNCTION IN CONDITIONS OF NORMAL USE. EXCEPT AS INDICATED ABOVE, IN NO EVENT WILL BUMPBOXX, LLC BE LIABLE FOR ANY DAMAGES CAUSED BY THE PRODUCT OR THE FAILURE OF THE PRODUCT TO PERFORM, INCLUDING ANY LOST PROFITS OR SAVINGS OR SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES. BUMPBOXX, LLC IS NOT LIABLE FOR ANY CLAIM MADE BY A THIRD PARTY OR MADE BY YOU FOR A THIRD PARTY. THIS LIMITATION OF LIABILITY APPLIES WHETHER DAMAGES ARE SOUGHT, OR A CLAIM MADE, UNDER THIS LIMITED WARRANTY OR AS A TORT CLAIM (INCLUDING LIMITATION OF LIABILITY), A CONTRACT CLAIM, OR ANY OTHER CLAIM. THIS LIMITATION OF LIABILITY CANNOT BE WAIVED OR AMENDED BY ANY PERSON. THIS LIMITATION OF LIABILITY WILL BE EFFECTIVE EVEN IF YOU HAVE ADVISED BUMPBOXX, LLC OR AN AUTHORIZED REPRESENTATIVE OF BUMPBOXX, LLC OF THE POSSIBILITY OF ANY SUCH DAMAGES. THIS LIMITATION OF LIABILITY WILL ALSO APPLY TO CLAIMS FOR PERSONAL INJURY.

To explore our full selection of products, please visit **www.bumpboxx.com**.
The illustrated products and specifications may differ slightly from those supplied.
All other trademarks and trade names are those of their respective owners.

Made In China

2016 Bumpboxx, LLC

Getting Started:

Connect the USB charging cable to the Micro USB charging port. Connect the opposite end to your power source and allow the speaker to fully charge before use. The Red charging Indicator LED will turn on when the battery is charging. When fully charged the LED will turn off. Press the power button to turn the speaker on. The Bumpboxx screen logo will flash while waiting to be paired with a Bluetooth device or Micro SD card to be inserted.

Connecting to Bluetooth:

On your Bluetooth enabled device search for and connect to the device named "Bumpboxx". The screen logo will stop flashing once the Bluetooth is connected.

Connect Two speakers with TWS pairing:

1. Turn on both speakers at the same time and the logo screens will begin to flash.
2. Press the power button quickly on one speaker and you will hear a beep. The logo screen on the opposite speaker will stop flashing to indicate that the 2 speakers are now connected.
3. Follow the steps above to pair only one speaker to the Bluetooth device named "Bumpboxx".
4. Once paired both logo screens will stay lit and the speakers are ready to play together.

Playing MP3 Files From a Micro SD Card:

Insert a Micro SD card into the slot to play music. The Bumpboxx logo will turn white once a Micro SD card is inserted. Music files must be MP3 format. Remove the Micro SD card to allow Bluetooth streaming. *Note: The Micro SD card capacity cannot exceed 32MB.

Answering Phone Calls:

When receiving an incoming phone call the speaker will play an audio alert. To answer the call press the Answer Call/End Call button. The microphone is located on the top of the speaker. To end the call press the Answer Call/End Call button.