
PANEL FUNCTIONS



1. Treble 2. Bass 3. Volume 4. USB 5. TF Card 6. Mode 7. Previous/Back 8. Play/Pause 9. Next 10. EQ Presets 11. Aux In 12. Aux Out 13. DC 15V Input 14. Power On 15. LED On 16. Charge Status

SPECIFICATIONS

Tweeters	2-2"	Charger Type	15V3A
Power	140 W	Rechargeable Lithium Ion Battery Length	22 Hours

ACCESSORIES

Adapter ×1	Remote Control	×1
Shoulder Strap x1	User Manual	x1

bumpboxx





OPERATION MANUAL

FUNCTION DESCRIPTION

REMOTE CONTROL

BATTERY AND POWER

- 1. Speaker features rechargeable battery.
- 2. Charge your battery using the included 22V4A charger.
- 3. LED light will glow red once charging. Fully charged, LED will turn blue.
- 4. Full recharge takes 3 to 4 hours.
- 5. Full battery could be used for up to 12 hours.
- 6. Please charge the battery for 4 to 5 hours before using for the first time.


BLUETOOTH CONNECTION

- 1. Press the "MODE" button to display "BLUE" on the screen to start connection.
- 2. The speaker is ready for pairing with a mobile device.
- 3. Scan for the speaker's name "Bumpboxx Ultra"
- 4. Pair via bluetooth.
- 5. Once paired, the volume and tracks can be controlled by both speaker's control panel and by the paired mobile device.

MODE CONTROL

- 1. Insert USB into USB slot. (Unit automatically changes to USB mode)
- 2. Insert TF into TF slot. (Unit automatically changes to TF mode)
- 3. Press select previous or next track, press to play or pause.

CAREFULLY READ THIS OPERATING MANUAL TO USE AND ENJOY THIS UNIT PROPERLY. KEEP THIS MANUAL HANDY FOR FURTHER REFERENCE.



Power
Mode
Mute
Play/Pause
Channel +/ EQ
Volume +/ Repeat
USB/SD
0-9