


## directional valve with left inlet


### "B" side options

#### SL type







#### SLP type (30 07 5338)

Mechanical control with dust-proof plate kit.



#### SLCZ type (30 07 7621)

Protection cap usable with pneumatic, electropneumatic, and electrohydraulic spool positioners.



#### Wrenches and tightening torques



X = allen wrench 4 - 6 Nm (4.4 lbf)

#### Wrenches and tightening torques


X = allen wrench 4 - 6 Nm (4.4 lbf)

## TQ cable remote control kit (30 07 5328)


Preadrilled for remote control with flexible cable.



(OPTIONAL)  
JS100 remote control



#### Example of cable control



#### Wrenches and tightening torques

X = allen wrench 4 - 6 Nm (4.4 lbf)

Y = wrench 10 - 9.8 Nm (7.2 lbf)

W = wrench 24 - 24 Nm (17.7 lbf)

NOTE : For further information about remote cable control, require related documentation.