PPE-1 Piston Pin Extractor Instructions


GOODSON


Tools and Supplies for Engine Builders


156 Galewski Drive • P.O. Box 847 • Winona, MN 55987-0847 Toll-Free 1-800-533-8010 • Local 507-452-1830 • www.goodson.com

PPE-1

Please read instructions before using.








"Safe-T" Pin Removal Guide

Note:

The parts of this kit were purposely left in their free machining state to permit easy alteration to suit special applications.

Caution!

Use caution in selecting the correct "Piston Adaptor" making sure adequate support is given to the piston and is large enough for piston pin.



Section showing application of "Safe-T" Pin Removal Guide. (for piston pin .875-1.000 dia.)

