

VST-95

Calibrated Spring Instructions

GOODSON

Tools and Supplies for Engine Builders

156 Galewski Drive • P.O. Box 847 • Winona, MN 55987-0847

Toll-Free 1-800-533-8010 • Local 507-452-1830 • www.goodson.com

VST-95

**Please read instructions
before using.**

Revised April 2013

Instructions

1. Spring has black mark on first ring indicating front and top. Place spring on platform with black mark facing you.
2. Compress spring to specified length and compare your tester with specified pressure indicated on calibration card supplied with test spring.

VST-95

Resorte Calibrado Instrucciones

GOODSON

Herramientas y suministros para reconstructores de motores

156 Galewski Drive • P.O. Box 847 • Winona, MN 55987-0847
Toll-Free 1-800-533-8010 • Local 507-452-1830 • www.goodson.com

VST-95

**Por favor leer las instrucciones
antes de usar**

Revisado Abril 2013

Instrucciones

1. El resorte tiene un punto negro en el primer anillo el cual indica la parte frontal superior. Coloque el resorte en la plataforma con la marca negra mirando hacia usted.
2. Comprima el muelle de prueba y ajuste la longitud especificada. Luego compare su probador de presión con las especificaciones indicadas en la tarjeta de calibración suministrada con el resorte de pruebas.