


Parts list

Item	Description	Quantity	Part number	Item	Description	Quantity	Part number
1	Reservoir	1	544-32584-1	21	Hose	1	444-24310-1*
2	5 wire internal plug	1	2)*	22	Screw	10	206-13796-7
3	Magnetic switch	1	544-60277-1*	23	Microprocessor	1	544-60222-1*
4	Closure plug	2	303-19285-1*	24	Sealing plug	1	544-36963-5*
5	Screw	3	1)	25	O-ring	1	219-14138-2
6	Washer	3	1)	26	Bearing ring	2	444-24168-1*
7	O-ring	3	1)	27	Eccentric cam	1	444-24170-2*
8	Pump housing	1	2)*	28	Snap ring	2	211-14100-1*
9	Pump element	1	3)	29	Inner ring	2	444-24439-1*
10	Gasket	1	3)	30	Shim	1	209-13047-5*
11	Check valve	1	3)	31	O-ring	2	219-13730-7*
12	Pressure relief assembly	1	624-77727-1	32	Intermediate plate	1	111-35089-2*
13	Nipple	1	226-14105-5	33	Bearing	1	250-14009-7*
14	3 wire internal plug	1	664-34041-9*	34	Control cam	1	444-24212-1*
15	Housing cover	1	544-32217-1*	35	Adapter	1	444-24167-1*
16	24 V  motor	1	1)	36	O-ring	1	111-35089-2*
17	Radial seal	1	1)	37	Stirring paddle	1	544-31954-1
18	Woodruff key	1	1)	38	Fixed paddle	1	444-70491-1
19	Fill adapter	1	278774	39	Hose	1	111-35089-2*
20	Plug for motor	1	1)	40	Piston detector ⁴⁾	1	664-85242-2, 9.8 ft (3 m) 664-85242-5, 23 ft (7 m)*
<p>1) Available for order in motor kit 544-36913-7*. 2) Not available for purchase. 3) Available for order in pump element assembly 600-26876-2*. 4) Part must be ordered separately. Does not come with pump. * Indicates change.</p>							