

# synxplus

## RelaxaPulse



# Tri-Directional Body Massager

## INSTRUCTION MANUAL

**Model No: SPTBM3**

To ensure correct usage of our synxplus tri-directional massager, we recommend you read this manual carefully prior to using the product. **Please keep the user manual on hand for easy reference.**

## BEFORE USING THE DEVICE

- Do not use the device if the packaging, the device itself, or the USB power cord show signs of damage.
- The device is not to be used for commercial use or medical purposes.
- Prior to using the device, please consult your medical or health practitioner if you have any health concerns.

## ABOUT THE DEVICE

### NAME AND FUNCTION OF PARTS

- The device provides 1 massage mode, with 3 massage intensity levels.
- These can be selected by pressing the **POWER** button.



The light will turn red when at the corresponding desired level.

1 - low speed vibration

2 - medium speed vibration

3 - high speed vibration

When the 'power' button is pressed, the lowest speed vibration (1) will commence.

Press a second time for the medium speed vibration (2).


Press a third time to achieve the highest speed vibration (3).

Press again for automatic mode.

Press one final time to power off the device.



USB-C CHARGING PORT



USB PLUG

USB-C PLUG

### BATTERY CHARGING

The device must be fully charged, prior to the first use.

It takes approximately 2.5 hours to fully charge the device.

The charging cable needs to be connected to a suitable USB output (5V 1A).

Whilst charging, if the battery charge is below 30%, one light will illuminate; when the battery is charged around 30 - 70%, two lights will illuminate; when the battery is charged around 70 - 99%, three lights will illuminate; when fully charged, 3 lights will illuminate. Then the device can be used for approximately 1.25 to 1.5 hours, depending on speed level used.




The device can be disconnected from the power supply, once it is fully charged.

When the massage intensity starts to reduce, it is recommended to cease using the device until it is fully charged again.

## USING THE DEVICE

Use the device by rolling it over the muscles as indicated in the images below. The device may assist:

- Release tight muscles and tension
- Boost circulation
- Reduce stress
- Improves relaxation and sleep



## IMPORTANT SAFETY INFORMATION

All instructions and precautions outlined in this manual should always be followed when using the product.

### DANGER

**To reduce the risk of electric shock:**

- The product must always be unplugged from the electrical outlet immediately after use and before cleaning.

### SAFETY FEATURE

The device has a safety feature which automatically turns off after 15 minutes of use.

It can be turned back on again and used until recharging is required.

### WARNING

**To avoid fire, electric shock, or injury to persons:**

1. Do not leave the device unattended when connected to mains power.
2. When not in use and before removing or replacing parts, the device must be unplugged from the mains power outlet.
3. Do not operate the device under a pillow or blanket/ bedding, as overheating may occur causing a fire, electric shock or injury to persons.
4. Do not carry this device by its supply cord or use the cord as a handle.
5. Do not operate the device whilst blocking the air openings. The air openings must remain dust, lint and hair free.

6. Do not use the device in damp rooms such as bathrooms or laundries, when showering or bathing.
7. Supervision is required if the device is being operated by or near children, or disabled persons.
8. Do not place the device's cord or the device itself, near heated surfaces.
9. Do not use the device if it has been dropped, immersed in water or appears damp.
10. The rechargeable batteries in this device are not replaceable.

## TROUBLESHOOTING

If problems are still being experienced after attempting to resolve them with our troubleshooting tips below, please contact SynxBody at [support@synxbody.com](mailto:support@synxbody.com)

| SYMPTOM               | CAUSE   | SOLUTION   |
|-----------------------|---|--|
| Device is not working | The power key has not been pressed.   | Press the power key.                                       |
|                       | The device will turn off automatically after it's completed a 15 minute session of use. | To continue using the device, press the power key again.   |
| Device is hot         | If the 15 minutes continuous use time has been exceeded, the device can overheat.       | Turn the device off and allow to cool down for 30 minutes. |

## TECHNICAL SPECIFICATIONS

Name: Synxplus Tri-Directional Body Massager.

Input: 5.0 V --- 1.0A



Made in China

## 12 MONTH WARRANTY

Thank you for purchasing your new Synxplus Tri-Directional Body Massager.

SynxBody warrants this product to be free from defects in materials and workmanship for 12 months from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided.

Please retain your receipt as proof of purchase and contact the SynxBody Support Team at [support@synxbody.com](mailto:support@synxbody.com) Or call **1300 096 265**. Warranty claims and claims for expense incurred in returning this product can be addressed to the SynxBody Support Team at PO Box 42, Hamilton Hill, WA 6963, Australia.

# synxplus

Keep your body in synx.

synxBody