



KODIAK PLUS ULTRA

PORTABLE
RUGGED

POWER BANK



WARNING: Use only a UL certified adapter when recharging the Kodiak USB Power Bank. The use of a USB to AC adapter that is not UL certified can cause high voltage and a spike in AC current, which in turn could cause the Power Bank, the adapter, or both to explode or catch on fire. To verify that the UL mark on the adapter has been certified by UL go to: http://database.ul.com/cgi-bin/XYV/template/LISEXT/1FRAME/index.html?utm_source=ulcom&utm_medium=web&utm_campaign=database

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Hi

Good call on picking up the Outdoor Tech® Kodiak Plus Ultra portable powerbank. Your experience of the universe will soon be enhanced powerfully. This manual exists to help make sure that you use them correctly, so you're definitely going to want to relax for a hot second and look through this.


Kisses,




CONTENTS

Anatomy	1
Charging Your Power Bank.....	2
Charging Stuff.....	3
Feature.....	5
Care & Maintenance	7
Specs.....	9


ANATOMY



- A. Battery Level Button
- B. Flashlight Button
- C. Micro USB Charge Port
- D. USB C - Quick Charge 3.0
- E. USB - Quick Charge 3.0
- F. Waterproof Seal
- G. Flashlight (White LED x5)
- H. Battery Level Indicator Lights (Red LED x4)




CHARGING YOUR POWER BANK




Charging your Kodiak Power Bank:

1. Connect the micro USB to the Kodiak Plus Ultra's micro USB input port.
 2. Connect the USB plug to your computer or power source.
- The red LED Lights will light up consecutively until all three red LEDs are lit. Once device is fully charged all three red LED lights will turn off.



CHARGING STUFF



2 Power Out Ports:

- USB - Quick Charge 3.0: 5V/3A, 9V/2A, 12V/1.5A
- USB C - Quick Charge 3.0: 5V/3A, 9V/2A, 12V/1.5A

Charging your devices:

1. Connect either a USB plug or USB C plug to the Kodiak Ultra's USB output port.
2. Connect the other end of cable to your device.
3. When your device is fully charged, disconnect the Kodiak Ultra.

■ CHARGING STUFF

What makes the Kodiak Plus Ultra so great? It's thin, light weight structure makes it the best friend who's got your back when you need an extra umph of charge at the end of the day.




Qualcomm® Quick Charge™ Technology provides simple, efficient battery charging of high-capacity batteries at speeds vastly superior to standard USB with standard cables and connectors.

USB-C is small, fast and high powered. USB-C is double-sided and reversible.

Qualcomm Quick Charge is a product of Qualcomm Technologies, Inc. and/or its subsidiaries. Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries. Quick Charge is a trademark of Qualcomm Incorporated. All Qualcomm Incorporated trademarks are used with permission.


4

■ FEATURES: WATERPROOF & SHOCKPROOF



■ FEATURES: WATERPROOF SEAL

Be sure the power seal is fully depressed all around the edges before exposure to different elements.



5

■ FEATURES: FLASHLIGHT / FUEL GAUGE

The Kodiak Plus Ultra has three flashlight settings:
- Low Beam, High Beam and Strobe



FUEL GAUGE:
Press 1x the red LED's in the flashlight will light up for a couple of seconds to show the battery level.

FLASHLIGHT:
- 1x ON/LOW BEAM
- press 1x again HIGH BEAM
- press 1x again SOS
- press 1x again OFF

Simply press once on the Flashlight (FL) Button to turn on the flashlight feature, low beam will light up. Then press the FL button one time again for high beam, then press one time again for strobe (SOS) and finally press one time to turn the flashlight off.

6

■ CARE & MAINTENANCE



- Do not access the input/output simultaneously. It may affect the product's performance and not charge properly.
- When not in use, please make sure the lid is tightly closed and kept away from extreme heat conditions.
- Keep the Kodiak Plus Ultra away from direct sunlight or hot places. High temperatures will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Use a soft, dry cloth to wipe the surface. Do not use intensive chemical products or detergent to clean the product.
- Charge the product at least once every three months, to prevent the batteries from drying out.

7

■ CARE & MAINTENANCE



- For best performance, fully charge the Kodiak Plus Ultra before charging other devices.
- Do not try to disassemble the Kodiak Plus Ultra.
- Do not scratch the surface with sharp things.
- It is normal for the battery to heat up during its charge. The temperature should be below 45° & does not affect the Kodiak Plus Ultra performance.
- All products have passed the strict quality inspection, Do not use the battery if it gives off an odor, generates heat, becomes deformed, abrasion, damaged or appears abnormal in any way.

*Quick Charge 3.0 will not work when the USB out and Type C out are being used simultaneously.

8

■ SPECS



- Power Output: USB - Qualcomm® Quick Charge™ 3.0 5V-3A, 9V/2A, 12V/1.5A
- Power Output: USB C - Qualcomm® Quick Charge™ 3.0 5V-3A, 9V/2A, 12V/1.5A
- Power Input: Micro USB - 5V/2A
- Flashlight: 100 Lumens
- IP67 Waterproof (when lid is closed)
- IPX6 Water resistant (when lid is open)
- Charge Time: 6.5 hours
- Weight: 0.64lbs (291g)
- Dimensions: 4.07in x 3.22in x 1.06in (103.5mm x 82mm x 27mm)
- Operating Temps: -20° to 60°C

9

DON'T BE SO ANTISOCIAL



Facebook.com/outdoortech
Twitter & Instagram: @outdoortech

Questions, comments, complaints, secret desires, or just to say what's up: email info@outdoortech.com

K bye.



www.outdoortech.com