

KODIAK ULTRA

POWER BANK







WARNING: Use only a UL certified adapter when recharging the Kodiak USB Power Bank. The use of a USB to AC adapter that is not UL certified can cause high voltage and a spike in AC current, which in turn could cause the Power Bank, the Accurrent, when in turn could cause the Power Bank, the adapter, or both to explode or catch on fire, To verify that the UL mark on the adapter has been certified by UL go to: http://database.ul.com/cgi-bin/XYV/template/LISEXT/1FRAME/index_html?utm_source=ulcom&utm_medium=web&utm_ campaign=database

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Good call on picking up the Outdoor Tech® Kodiak Ultra portable powerbank, Your experience of the universe will soon be enhanced powerfully. This manual exists to help make sure that you use them correctly, so you're definitely going to want to relax for a hot second and look through this.

Kisses,


Hi





Charging Your Power Bank.... Charging Stuff......3 Feature......5 Care & Maintenance

CONTENTS







D. USB C Port 5V/2.4A

E. USB Output Port 5V/2.4A

F. Waterproof Seal

G. Flashlight (White LED x5)


H. Battery Level Indicator Lights (Red LED x4)



Charging your Kodiak Power Bank:

- 1. Connect the micro USB to the Kodiak Ultra's micro USB input port.
- 2. Connect the USB plug to your computer or power source.
- The red LED Lights will light up consecutively until all three red LEDs are lit. Once device is fully charged all three red LED lights will turn off.

micro USB input port



0% - 25% >> 25% - 50% >> 50% - 75% >> 75% - 100% 1 red LED lit 2 red LED's lit 3 red LED's lit 4 red LED's lit CHARGING STUFF



USB output port and USB C Charging your devices:

- 1. Connect either a USB plug or USB C plug to the Kodiak Ultra's USB output port.
- 2. Connect the other end of cable to your device.
- 3. When your device is fully charged, disconnect the Kodiak Ultra.

■ CHARGING STUFF

What makes the Kodiak Ultra so great? It's thin, light weight structure makes it the best friend who's got your back when you need an extra umph of charge at the end of the day.

INTELLIGENT CHARGE TECHNOLOGY



The Kodiak Ultra's INTELLIGENT CHARGE TECHNOLOGY will detect the optimal charging output for the device that's plugged into the power bank



USB out - 5V/2.4A with INTELLIGENT CHARGE TECHNOLOGY.

■ FEATURES: WATERPROOF & SHOCKPROOF




■ FEATURES: WATERPROOF SEAL

Be sure the power seal is fully depressed all around the edges before exposure to different elements.



FEATURES: FLASHLIGHT / FUEL GUAGE

The Kodiak Ultra has three flashlight settings: - Low Beam, High Beam and Strobe



FUEL GAUGE: Press 1x the red LED's in the flashlight will light up for a couple of seconds to show the battery level.

FLASHLIGHT:

- 1x ON/LOW BEAM
- press 1x again HIGH BEAM
- press 1x again SOS
- press 1x again OFF

Simply press once on the Flashlight (FL) Button to turn on the flashlight feature, low beam will light up. Then press the FL button one time again for high beam, then press one time again for strobe (SOS) and finally press one time to turn the flashlight off.

■ CARE & MAINTENANCE



- Do not access the input/output simultaneously. It may affect the product's performance and not charge properly.
- When not in use, please make sure the lid is tightly closed and kept away from extreme heat conditions.
- Keep the Kodiak Ultra away from direct sunlight or hot places. High temperatures will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Use a soft, dry cloth to wipe the surface. Do not use intensive chemical products or detergent to clean the product.
- Charge the product at least once every three months, to prevent the batteries from drying out.

■ CARE & MAINTENANCE



- For best performance, fully charge the Kodiak Ultra before charging other devices.
- Do not tru to disassemble the Kodiak Ultra.
- Do not scratch the surface with sharp things.
- It is normal for the battery to heat up during its charge. The temperature should be below 45° & does not affect the Kodiak Ultra performance.
- All products have passed the strict quality inspection, Do not use the battery if it gives off an odor, generates heat, becomes deformed, abrasion, damaged or appears abnormal in any way.

SPECS



- Power Output, USB: 5V/2.4A
- Power Output, USB C: 5V/2.4A
- Power Input, Micro USB: 5V/2A
- Flashlight: 100 Lumens
- IP67 Waterproof (with lid closed)
- IP6 Water resistant (with lid open)
- Charge Time: 4 hours
- Weight: 0.49lbs (225q)
- Dimensions: 4.071in x 2.5in x 1.06in (103.5mm x 63.5mm x 27mm)
- Operating Temps: -20° to 60°C

DON'T BE SO ANTISOCIAL







Facebook.com/outdoortechnology Twitter & Instagram: Coutdoortech

Questions, comments, complaints, secret desires, or just to say what's up: email info@outdoortech.com K bye.



www.outdoortech.com

Charging times: