



OUTDOOR TECH.®

ORCAS

**ACTIVE
WIRELESS**

**EAR-
BUDS**



Hi.



Good call on picking up the Outdoor Tech® Orcas wireless earbuds. Your experience of the universe will soon be enhanced wirelessly. This manual exists to help make sure that you use them correctly, so you're definitely going to want to relax for a hot second and look through this.

Kisses,




OUTDOOR TECH.

■ CONTENTS

What's Inside	1
Anatomy	2
Power Up	4
Pairing	5
Talk	6
Features	9
Specs	12
FAQ	13
Care & Maintenance	14

WHAT'S INSIDE

+ ORCAS Earbuds



+ Three Sizes of Fins and COMPLY™ Eartips




+ ORCAS wire clip  (already attached)

+ Micro USB charging cable

+ Instruction manual

+ Two ODT stickers

ANATOMY



● LED indicator

● Charging jack

● Microphone (on reverse)

● Volume/Track control


● Multi-function button

■ ANATOMY



Function	Action	Voice Prompt
Power On / Off	Hold the MFB Ⓜ	"Power on" / "Power off"
Play/Pause/Answer/ Hang up	Press the MFB Ⓜ	N/A
Raise volume	Press up ⏪	N/A
Lower volume	Press down ⏩	N/A
Skip forward	Hold up ⏪	N/A
Skip back	Hold down ⏩	N/A
Voice command/Siri	Short press the MFB & up Ⓜ ⏩	"Voice dial"

■ POWER UP



For best results, fully charge your Orcas before use.

For a full charge, plug the Orcas into your wall charger or computer via micro USB cable.

The LED indicator located below the right ear piece will flash red to indicate a low battery.

NOTE: It takes 2 hours to give your Orcas a full charge.

■ PAIRING



Entering Pairing Mode

1. Hold the "multifunction button ()" down until the LED flashes red and blue alternately.
2. Release "button," you are now in pairing mode.

Pair

Go to your device's Bluetooth settings

ADD or SEARCH devices.

When "ODT ORCAS" appears, select it.

*If asked for a pass code: Enter "0000"

After successfully connecting, the blue LED will flash twice every 4 seconds. The voice prompt will state "Connected."

You should now be able to play music & make/receive calls using the headset. Hooray.

■ TALK



The following are tips on how to use your Orcas to talk on the phone. Just a heads up... the voice prompt is British, which is kinda funny. And just so you're not surprised, she always states the phone number of the incoming call. Have fun.

TALK (HOW TO)

Function	Action	Voice Prompt
Answer	Press the MFB 	"Answer"
End a call	Press the MFB 	"Call terminated"
Decline a call	Press & hold the MFB 	"Reject"
Make a call	Use your phone to dial as usual or use Siri to dial	N/A
Mute/Cancel mute	Press & hold up ⏪	"Mute on" / "Mute off"
Transfer conversation to mobile phone or headset during a call	Hold the MFB 	"Transfer audio"
Volume up during a call	Short press up ⏪	N/A
Volume down during a call	Short press down ⏩	N/A
Voice dial	Short press the MFB 	N/A
Put call on hold	Double press the MFB 	*Beep*
Redial last number	Double click the MFB button 	"Last number redialed"


TALK (THE FANCY STUFF)

You're popular. What happens when you're on a call with your girlfriend and your mom calls?



Answer new call & end current call:	Short press the multifunction button 
Answer new call & retain current call:	Double click the multifunction Button 
Switch calls:	Double click the multifunction Button 
End current call & switch retained call:	Short press the multifunction Button 

FEATURES: ORCA FINS & LIQUIPEL



THE ORCA "FINS" PROVIDE A **SUPER** LEGIT FIT.

AND WE HAVE **FIT OPTIONS** FOR EVERYONE



LIQUIPEL



ARE YOU A **SWEATY ANIMAL**?
NO WORRIES. ORCAS ARE
COATED WITH **LIQUIPEL**.
THAT MEANS **SWEATPROOF** BABY.

FEATURES: COMPLY™ & EARBUDS

Includes

COMPLY™
Premium Earphone Tips



SO, JUST WHEN YOU THOUGHT
THE ORCAS COULDN'T GET ANY BETTER...

We totally get that it's really annoying when your earbuds pop out of your ears when you workout. Have no fear! We have solved this issue for you by using earbuds designed by COMPLY™! These earbuds stay perfectly snug in your ear no matter what activity you are doing to get your sweat on.



HOW TO INSERT YOUR COMPLY™ EARBUD

1. Roll the tip into a thin, round cylinder.



2. Pull back and up on your ear to open the canal. Gently insert the entire earbud into your ear.



3. Hold the tip in place until the COMPLY™ earbud expands in your ear canal.

* That is some scientific stuff right there.

CHANGING YOUR COMPLY™ EARBUD

Pinch the old tip and twist off. Clean earphone nozzle of any debris. Secure the new earbud onto the clean nozzle.

*Replace every 3 months.. stay hygienic people.




FEATURES: ORCAS CLIP

So, just in case you have extra slack on your Orcas wire that annoys you while you're running, we've added a clip that you can shorten your Orcas!



The wire is fed through these two sections in the clip! There is an open side in case you choose not to shorten the Orcas.



The Orcas wire is already fed through one of the closed openings on the clip. If you choose to shorten the slack on your Orcas to prevent the wire from jostling around, just take more of the wire and feed it through the other opening. (make it look like the above image!)

■ SPECS



Battery Life: Continuous talk/music time 6 hours,
Standby time/150 hours

*Battery life varies subject to different playing circumstances such as music type and volume.

Bluetooth Version: V4.0

Bluetooth Profiles: A2DP, aptX, AVRCP

Operating distance: 32 feet

Dimensions: 37 x 16 x 28 mm

Weight: 13g

FAQ

1. Why is the LED flashing red instead of blue?

The battery is low. Recharge it.

2. Why is the red LED off when charging?

A. Make sure the connection between the charging cable and the Orcas is tight.

B. If the Orcas haven't been used in awhile, the light may not come on immediately. Charge the battery for at least 30 minutes.

3. Why cant I pair my Orcas?

Your Bluetooth device and the chips must both be in pairing mode.

4. Why can't I hear the sound on the headset?

A. Make sure the Orcas are on.

B. Make sure the volume is not too low or muted.

C. Make sure the Orcas are properly connected with your device.

D. Make sure the Orcas are within range of your device.

5. Why can't I hear the sound clearly on the headset?

A. Move your orcas closer to your device.

B. Make sure your Orcas are charged up.

C. Turn off your Orcas and device, then power up and reconnect.

6. Why the pause/play, last/next song not function when playing music?

Make sure your Bluetooth device supports AVRCP (Audio/Video Remote Control profile)

CARE & MAINTENANCE



- **Keep the Orcas Dry**
- **Keep the Orcas away from direct sunlight or hot places. High temperatures will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.**
- **Do not try to disassemble the Orcas.**
- **Do not let the Orcas fall onto the floor or other hard surfaces. The internal circuit board may get damaged.**
- **Do not use intensive chemical products or detergent to clean the product.**
- **Do not scratch the surface with sharp things.**

K, bye.

DON'T BE SO ANTISOCIAL



Facebook.com/outdoortech

Twitter & Instagram: @outdoortech

Questions, comments, complaints, secret desires,
or just to say what's up: email info@outdoortech.com

K bye.



outdoortech.com