

Vent Damper Installation Instructions

Ensure that the Damper fits the vent. Note, the size vent the Damper is meant for is stamped into the metal on the Damper itself. In the case of this photo, the vent is a 4" x 10". Turn the Damper over so that the Adjustment Wing fits through either one of the end vent openings:






Note that one edge of the Damper has tabs along its edge. These tabs can be pulled out (loosened) to allow the Damper to be fitted to the vent or pushed in to lock the Damper onto the vent:




Pull out the tabs to loosen one side of the Damper so that it will fit over the milled edge of the vent:





Click down the edge of the Damper onto the vent and then push back in the tabs to lock the Damper to the vent:



Note that the tab is "pushed in" to lock the Damper to the vent:





Looking down from the top: Vent with installed Damper. Adjustment Wing slides from side to side to open/increase or close/decrease air flow:

