



SITE:1

*your craft audio listening experience
is about to begin...*

version 1.3.2

getting to know your Site:1




WHAT'S IN THE BOX

- Site:1 Speaker
- User Guide
- 2.5 mm–3.5 mm AUX Cable
- Warranty Registration Card
- Charging Cord

GRILLE ORIENTATION

Magnets on Grille
Must Be Positioned
North and South for
Proper Alignment



WIRED SET-UP (default setting)

- Press power button to power on.
- Press the User Control Dial twice to enter play mode.
- Turn the User Control Dial until a white LED is in the outside position on both sides (see diagram). Press to enable mode.
- Play via a wired connection using your source device.
- Turn the User Control Dial to adjust volume (blue LEDs).

BLUETOOTH STEREO SET-UP


(wireless pairing with another site:1)

- Press power button on both units to power on.
- Press the User Control Dial on the right Site:1 twice to enter play mode.
- Turn the User Control Dial on the right Site:1 until a blue LED is in the sixth position (see diagram). Press to enable mode.
- Turn the User Control Dial on the left Site:1 until a blue LED is in the second position (see diagram). Press to enable mode.
- Allow alternating red/blue LEDs to stop flashing, indicating a successful pairing.
- Using a Bluetooth-enabled device, select Site:1 (stereo) from the Bluetooth settings and connect.
- Turn the User Control Dial on either Site:1 to adjust volume (blue LEDs).

Site:1 may be reset at any time by pressing the power button.

BLUETOOTH® SET-UP

- Press power button to power on.
- Press the User Control Dial twice to enter play mode.
- Turn the User Control Dial until a single blue LED is in the center position (see diagram). Press to enable mode.
- Using a Bluetooth-enabled device, select Site:1 from the Bluetooth settings and connect.
- Turn the User Control Dial to adjust volume (blue LEDs).



TRACK ADVANCE

In Bluetooth mode, press and hold dial for 2-3 seconds until yellow LEDs appear. Turn dial a single click forward to skip a track or a single click back to replay a previous track.


CHECKING BATTERY LIFE

Press the User Control Dial to check battery. LED color indicates battery life remaining.

- = 40-100% (green LED)
- = 10-40% (yellow LED)
- = below 10% (red LED)

CHARGING THE BATTERY

- Press power button to power on.
- Connect charging cord to charge port on the back of the Site:1 and to a power source.
- LED flashes red when charging.
- LED flashes green when fully charged.

A photograph of three people sitting around a campfire at night. The scene is illuminated by the warm glow of the fire and a lantern. The background shows a dark forest and a body of water. Three small, triangular speakers are placed around the campfire. The text 'Site:1 in stereo... better together' is written in a yellow, handwritten font in the upper left corner.

Site:1 in stereo... better together

The beauty of Princeton Audio's Craft Audio experience is its flexibility. You can start with one Site:1 and add a second at any time in the future. They will pair and produce true stereo sound, separate and play independently then pair again to play stereo. With one user interface, using your speaker is easy!



BLACK WALNUT

- warm, balanced sound
- provides a full-bodied bass with abundant crisp midtones and sustained treble integrity
- overtone clarity similar to mahogany yet not quite as bright as maple

Ideal for Rock & County



CHERRY

- gives a unique neutrality for a more articulate projection of midtones
- produces a clean sound
- avoids any favoring of bass or treble creating a mellow ambience and listening experience

Ideal for Choral & Orchestral



MAHOGANY

- its lighter, eloquent nature yields a thicker, sincere midrange presence
- the airy composition allows for brighter highs and warmer lows, which all together form a fluid, smooth sound

Ideal for Jazz & Blues



MAPLE

- its higher density produces a brighter, prominent sound
- exceptional bass and treble which coupled with its excellent separation results in a strong, crisp audio experience

Ideal for Electronic & Hip Hop

Let us help you craft your stereo sound.

CALL US AT 920.354.6340. WE CAN HELP YOU SELECT THE PERFECT PARTNER TO YOUR NEW SITE:1.



princeton audio

 544 W. WATER ST. PRINCETON WI 54968  920.354.6340  WWW.PRINCETON-AUDIO.COM

Love your new speaker? Please share your experience!

