

CLOUD CAP GRAVEL PUMP

Tips:

- BE KIND TO YOUR BACK! It's nice to have the tire valve in the 12 o'clock position for hand pumping.



- Get to know your new pump before you use it for the first time on a ride. Try twisting the control knob and unthreading the nozzle for Presta mode (don't forget it's reverse thread, so the opposite of righty tighty lefty loosey.)

For Presta Valves:



1. Open Presta valve and tap the tip to make sure air can move freely.
2. Turn the pump nozzle clockwise (reverse thread!) and pull it out.
3. Thread pump nozzle onto the tube valve.
4. Pump by hand or continue to CO2 inflation section.

CO2 Inflation:



1. Make sure the control knob is closed.
2. Thread CO2 cartridge onto the pump until it punctures
3. Open control knob to release CO2

Tip: Only release a small amount of CO2 at first to make sure it is flowing properly into the tire.

4. When finished inflating, twist the control knob closed and unthread the nozzle from the valve.

