

**Asteroid™**

www.ridepdw.com | 503-234-7257

## Battery Care


- Fully charge your Asteroid™ before first use.
- Lithium-ion batteries naturally lose charge over time. Charge your Asteroid™ if you haven't used it in over 7 days.
- If storing for an extended period of time, fully charge your Asteroid™ at least once every 4 months

## Warranty

PDW provides warranty coverage against manufacturing defects for 2 years from date of purchase. Batteries are under warranty for 1 year from date of purchase, excluding misuse.

Please contact us for warranty questions at [info@ridepdw.com](mailto:info@ridepdw.com).

## Charging



Plug smaller end of USB cable into the Asteroid™ and the other end into a USB port on a computer or wall socket adapter.

Flashing Blue indicates charging.

Solid Blue indicates charged.

Your Asteroid™ will charge from depleted to full in 2 hrs 15 mins.

## Operation

- To turn on and off, **DOUBLE** click the lens.
- With your light turned on, you can click through ON, Pulse, and Flash modes.
- Your Asteroid™ remembers the last mode you used and will turn on in the same mode.
- When the battery is almost depleted, an indicator LED will turn on and your Asteroid™ will switch to slow flashing mode. Approximately 30 minutes of battery life remain once the slow flashing mode starts.
- Your Asteroid™ will automatically turn off when fully depleted to protect the battery. Your light must be charged before it will turn on again.

For additional help and videos, visit [ridepdw.com/product-help](http://ridepdw.com/product-help)

## Mounting

