

ridepdw.com | 503-234-7257 3625 SE 21st Ave Portland, OR 97202

P∧THFINDER™

Battery Care


- Fully charge your Pathfinder™ before first use.
- Charge your Pathfinder™ after each use. Never store a fully depleted light.
- Lithium-ion batteries naturally lose charge over time so top off your Pathfinder™ if you haven't used it in over 4 days.
- If storing for an extended period of time, fully charge your Pathfinder™ at least once every 4 months.

Warranty

PDW provides warranty coverage against manufacturing defects for 2 years from date of purchase. Batteries are under warranty for 1 year from date of purchase, excluding misuse.

Please contact us for warranty questions at info@ridepdw.com.

Charging



Plug smaller end of USB cable into the Pathfinder™ and the other end into a USB port on a computer or wall socket.

Charging = Flashing green

Fully Charged = Solid green for 10 minutes then no green to preserve charge

The Pathfinder™ will charge from depleted to full in 3 hours.

Operation

- •To turn on and off hold button for 1 second.
- With your light turned on you can click through low, high, pulse and flash modes.
- Your Pathfinder™ remembers the last mode you were in when you turned the light off and will turn on in the same mode the next time you use it.
- Light will automatically turn off to protect the battery when the battery is fully depleted.

Mission Control 2.0

