



INSTRUCTIONS FOR INSTALLATION OF WIRED DOOR BELL KIT

THIS IS A PREASSEMBLED KIT

PUSH BUTTON

- 1. Wiring for the pushbutton will be labeled "button"**
- 2. Drill hole in wall or door frame to run wire thru**
- 3. Drill holes to mount pushbutton**
- 4. Run wire thru the drilled hole and reattach wire to the pushbutton**
- 5. Secure pushbutton to wall with included screws.**

FIRE BELL

- 1. Remove bolt from Fire Bell to expose mounting plate**
- 2. Use screws to attach Fire Bell Mounting plate to desired location**
- 3. Reattach Fire Bell to mount plate with bolt removed in step 1.**

GREY PVC BOX

- This will contain relay and does not need to be opened**
- Secure the box at desired location with screws at each of the four corners.**

POWER SUPPLY

- Plug into any standard 110 to 120 volt outlet**

WIRED KIT WITH TIMER

- To adjust the timed output remove the cover for the GREY PVC BOX and turn the white knob.**
- To adjust from seconds to minutes setting move switch #2 to the OFF position**

CALL 800-641-4111 SHOULD THERE BE ANY QUESTIONS