


For a Temperature sensor, connect CHx- to the sensor blue wire and to SSI-4 GND, and CHx+ to the sensor green wire and to SSI-4 5V via a 2K7 resistor.

For a Pressure sensor, connect CHx- to the sensor ground wire and to SSI-4 GND, CHx+ to the sensor signal wire, and sensor 5V to SSI-4 5V.

Connect the SSI-4 to Ignition switched 12V and to Battery Negative.

Chain any upstream LC-2 into the SSI-4 SERIAL IN. Connect the SSI-4 SERIAL OUT into GaugePilot



## GP-I04 Innovate SSI-4

Sheet 1 of 1

30th March 2016 Revision: R2

(c) 2016 Hambly Industries Limited

**GaugePilot**

