

IN-LINE MIC

THE IN-LINE MIC HAS MAGICAL PROPERTIES



The in-line mic is great for hands-free communication but it also has some other great secret features that can be activated by pressing the button. The recipes for magic are as follows:

●	= one press of the button	
⦿	= long press of the button (Hold for three seconds)	
	i O S	ANDROID
●	Answer or End a call Play/Pause your music	Mute/Unmute mic in call Play/Pause your music
●●	Go to next track	Go to next track
●●●	Previous track	N/A
⦿	Activate voice control	Answer or End a call Activate voice control


The in-line mic button may act differently on different Android devices.

NO SLIP WITH ANCHOR FIT



PUTTING ON THE FANG

- 1) Slip the earbud into your ear like the image shown.
- 2) The hook point faces forward towards your nose. It should slip into the middle crease in your ear. This secures the earbud.
- 3) Push the cushion into your ear for a good seal.
(when removing the FIGHT do not pull on the cord, this can damage the earbud).



3 CUSHION SIZES FOR MAXIMUM COMFORT

For the best sound performance, and the most comfortable fit, try out each ear cushion. Choose a cushion that easily fits into your ear, feels comfortable, and is easy to remove.

REPLACING THE CUSHIONS


- 1) Gently pull the cushion to remove it.
- 2) Twist and push to ease on the new one.

THE ANCHOR FIT COMFORT HOOK



No slip with Anchor Fit.

THE Y SPLITTER



- 1) Remove the upper part of the Y splitter by pulling it upwards
- 2) Pull it up to the mic to help reduce tangles.

SPECS

DRIVER / BOBINA 10 mm Neodymium
SENSITIVITY / SENIBILIDAD 102 dB
FREQUENCY / FRECUENCIA 20-20,000 Hz
IMPEDANCE / IMPEDANCIA 16 Ohms
CORD LENGTH / LONGITUD DEL CABLE 4 ft / 1.2 m
PLUG MATERIAL Gold Plated / Chapado en Oro
IN-LINE MIC / MICROFONO INTEGRADO

Anchor Fit	Active	Sweat Resistant	Noise Isolation
Tangle Free	Enhanced Bass	Hands Free	3 Cushions



FVNG

PRECAUTIONS

LISTENING TO AUDIO AT EXCESSIVE VOLUMES CAN CAUSE PERMANENT HEARING DAMAGE. USE AS LOW A VOLUME AS POSSIBLE.

Over exposure to excessive sound levels can damage your ears resulting in permanent noise-induced hearing loss (NIHL). Please use the following guidelines established by the Occupational Safety Health Administration (OSHA) on maximum time exposure to sound pressure levels before hearing damage occurs.

SAFE USE & HAZARD WARNINGS

90 dB SPL at 8 hours	95 dB SPL at 4 hours	100 dB SPL at 2 hours	105 dB SPL at 1 hours
110 dB SPL at 30 min.	115 dB SPL at 15 min.	120 dB SPL	Avoid as damage may occur

ADVERTENCIA

ESCUCHA DEL AUDIO NIVELES EXCESIVOS DE VOLUMEN PUEDE CAUSAR DAÑOS PERMANENTES AUDIENCIA. SE USE COMO VOLUMEN MÁS BAJO POSIBLE.

Durante la exposición a niveles excesivos de ruido puede dañar los oídos resultando en ruido permanente pérdida de audición inducida (PAIR). Por favor, use las siguientes pautas establecidas por la Administración de Seguridad de Salud Ocupacional (OSHA) de tiempo máximo que los niveles de presión de sonido antes de que se produce una lesión auditiva.

USO SEGURO DE PELIGROS Y ADVERTENCIAS

90 dB SPL at 8 hours	95 dB SPL at 4 hours	100 dB SPL at 2 hours	105 dB SPL at 1 hours
110 dB SPL at 30 min.	115 dB SPL at 15 min.	120 dB SPL	Avoid as damage may occur

LIFETIME WARRANTY

Keep your receipt to obtain warranty service.
Go to www.wickedaudio.com for more details.

GARANTÍA DE POR VIDA

Guarde su recibo para obtener servicio de garantía.
Hora de salida www.wickedaudio.com para más detalles.

IN-LINE MIC

THE IN-LINE MIC HAS MAGICAL PROPERTIES



The in-line mic is great for hands-free communication but it also has some other great secret features that can be activated by pressing the button. The recipes for magic are as follows:

●	= one press of the button	
⦿	= long press of the button (Hold for three seconds)	
	i O S	ANDROID
●	Answer or End a call Play/Pause your music	Mute/Unmute mic in call Play/Pause your music
●●	Go to next track	Go to next track
●●●	Previous track	N/A
⦿	Activate voice control	Answer or End a call Activate voice control


The in-line mic button may act differently on different Android devices.

NO SLIP WITH ANCHOR FIT



PUTTING ON THE FANG

- 1) Slip the earbud into your ear like the image shown.
- 2) The hook point faces forward towards your nose. It should slip into the middle crease in your ear. This secures the earbud.
- 3) Push the cushion into your ear for a good seal. (when removing the FIGHT do not pull on the cord, this can damage the earbud).



3 CUSHION SIZES FOR MAXIMUM COMFORT

For the best sound performance, and the most comfortable fit, try out each ear cushion. Choose a cushion that easily fits into your ear, feels comfortable, and is easy to remove.

REPLACING THE CUSHIONS


- 1) Gently pull the cushion to remove it.
- 2) Twist and push to ease on the new one.

THE ANCHOR FIT COMFORT HOOK



No slip with Anchor Fit.

THE Y SPLITTER



- 1) Remove the upper part of the Y splitter by pulling it upwards
- 2) Pull it up to the mic to help reduce tangles.

SPECS

DRIVER / BOBINA 10 mm Neodymium
SENSITIVITY / SENIBILIDAD 102 dB
FREQUENCY / FRECUENCIA 20-20,000 Hz
IMPEDANCE / IMPEDANCIA 16 Ohms
CORD LENGTH / LONGITUD DEL CABLE 4 ft / 1.2 m
PLUG MATERIAL Gold Plated / Chapado en Oro
IN-LINE MIC / MICROFONO INTEGRADO

Anchor Fit	Active	Sweat Resistant	Noise Isolation
Tangle Free	Enhanced Bass	Hands Free	3 Cushions



FVNG

PRECAUTIONS

LISTENING TO AUDIO AT EXCESSIVE VOLUMES CAN CAUSE PERMANENT HEARING DAMAGE. USE AS LOW A VOLUME AS POSSIBLE.

Over exposure to excessive sound levels can damage your ears resulting in permanent noise-induced hearing loss (NIHL). Please use the following guidelines established by the Occupational Safety Health Administration (OSHA) on maximum time exposure to sound pressure levels before hearing damage occurs.

SAFE USE & HAZARD WARNINGS

90 dB SPL at 8 hours	95 dB SPL at 4 hours	100 dB SPL at 2 hours	105 dB SPL at 1 hours
110 dB SPL at 30 min.	115 dB SPL at 15 min.	120 dB SPL	Avoid as damage may occur

ADVERTENCIA

ESCUCHA DEL AUDIO NIVELES EXCESIVOS DE VOLUMEN PUEDE CAUSAR DAÑOS PERMANENTES AUDIENCIA. SE USE COMO VOLUMEN MÁS BAJO POSIBLE.

Durante la exposición a niveles excesivos de ruido puede dañar los oídos resultando en ruido permanente pérdida de audición inducida (PAIR). Por favor, use las siguientes pautas establecidas por la Administración de Seguridad de Salud Ocupacional (OSHA) de tiempo máximo que los niveles de presión de sonido antes de que se produce una lesión auditiva.

USO SEGURO DE PELIGROS Y ADVERTENCIAS

90 dB SPL at 8 hours	95 dB SPL at 4 hours	100 dB SPL at 2 hours	105 dB SPL at 1 hours
110 dB SPL at 30 min.	115 dB SPL at 15 min.	120 dB SPL	Avoid as damage may occur

LIFETIME WARRANTY

Keep your receipt to obtain warranty service.
Go to www.wickedaudio.com for more details.

GARANTÍA DE POR VIDA

Guarde su recibo para obtener servicio de garantía.
Hora de salida www.wickedaudio.com para más detalles.