


Truspeed SSD IV wireless digital controllers



These are quality digital controllers that work with the Scalextric Sport Digital Advanced Powerbase (APB) via the Slot Car Solutions wireless receiver.

With wireless controllers, drivers can move around the track and get up close to the display monitors and to the pit lane.



Sensitivity knob - turn left (anti-clockwise) for more gentle acceleration. Turn right (clockwise) for faster acceleration.

On-Off switch - the controller will switch itself off when not in use. If your controller is not working, use this switch to turn off and then on again.

Black 'Lane Change' button - this button is used to change lanes during a race. However, it also has menu functions in RCS64:

- Tyre choice before a race
- Press & hold brings up pit menu
- Scrolls through options in pit menu

Red 'Brake' button - this button is used to brake during a race. However, it also has menu functions in RCS64:

- Lights up the 'Ready' box before a race
- Stops car in pits
- 'Select' button in pit menu