


ITEM NO.	PartNo	DESCRIPTION	Exploded Main Components/ QTY.
1	BU0001	Backframe	1
2	BU0006	Bottom Frame	1
3	BU0014	Flat Spacer	4
4	31411105	Washer	4
5	31112212	Bolt	5
6	3112219	Bolt	4
7	31112217	Hex Bolt	2
8	60136	Washer	18
9	BU0005	Upright	1

Tracmaster Ltd
 Tel: +44 (0) 144 247689
 www.tracmaster.co.uk

Parts Diagram

Buck Rake Main Assembly

VALID FROM	SEPTEMBER 2018
SERIAL NUMBER	A70-10000
REVISION	A



ITEM NO.	PartNo	DESCRIPTION	Rear Assembly/QTY.
1	BU0005	Upright	1
2	BU0011	Long Spacer	1
3	BU0007	Square Spacer	2
4	BU0013	Medium Spacer	2
5	BU0012	Small Spacer	1
6	12926	Washer	12
7	BU0014	Hex Bolt	2
8	31241120	Nyloc	6
9	31112212	Bolt	1
10	31241100	Nyloc	1
11	BU0004	Brace	3
12	BU0003	Mounting Arm	1
13	BU0002	Arm	1
14	60136	Washer	2
15	31112217	Hex Bolt	1
16	31112217	Hex Bolt	2

Tracmaster Ltd
 Tel: +44 (0) 144 247689
 www.tracmaster.co.uk

Parts Diagram

Buck Rake Rear Assembly

VALID FROM

SEPTEMBER 2018

SERIAL NUMBER

A70-10000

REVISION

A