



Child Safety Sliding Cabinet Locks

Secure cabinet doors easily and quickly without drilling, helping keep curious toddlers out of the cabinets.

To Use:



1. Open lock by pressing the two A buttons with your thumb and finger, and slide the buckle till the end.

2. It closes with a simple sliding action. Place the U shape lock (part C) around the closed cabinet knobs or handles,

and slide the buckle (part B) till the lock is tight and cannot move further. Tug firmly on the handles or knobs to check for a secure fit. The cabinets should not create a gap larger than 1.

Notice to Parents:



This is not a toy. All small products can be a choking hazard. This product cannot take place of adult supervision. Never leave children unattended, and we highly recommend placing medicines and household chemicals on the top cabinets to avoid any accidents. Once lock is damaged, please discard immediately. Might not fit very small mushroom shaped knobs.

We'd like to know what you think and more importantly, for you to share with your friends on: [@surebasics](https://www.instagram.com/surebasics)



If you have any issues in the future, please email info@surebasics.com and we will do all we can to solve your issue.

